

Service Instructions

for use by heating contractor

VIESSMANN®

Vitocrossal 300 CU3A

Models 26, 35, 45, 57, 94, 125, 160, 199

Floor mounted, gas-fired condensing boiler with MatriX gas burner and Lambda Pro control

For operation with natural gas and liquid propane gas

Heating input 19 to 199 MBH

5.6 to 58 kW



VITOCROSSAL 300



Product may not be exactly as shown

IMPORTANT

**Read and save these instructions
for future reference.**

Safety, Installation and Warranty Requirements

Please ensure that these instructions are read and understood before commencing installation. Failure to comply with the instructions listed below and details printed in this manual can cause product/property damage, severe personal injury, and/or loss of life. Ensure all requirements below are understood and fulfilled (including detailed information found in manual subsections).

■ Product documentation

Read all applicable documentation before commencing installation. Store documentation near boiler in a readily accessible location for reference in the future by service personnel.

►For a listing of applicable literature, please see section entitled "Important Regulatory and Installation Requirements".



■ Warranty

Information contained in this and related product documentation must be read and followed. Failure to do so renders the warranty null and void.



■ Licensed professional heating contractor

The installation, adjustment, service and maintenance of this equipment must be performed by a licensed professional heating contractor.

►Please see section entitled "Important Regulatory and Installation Requirements".



■ Contaminated air

Air contaminated by chemicals can cause by-products in the combustion process, which are poisonous to inhabitants and destructive to Viessmann equipment.

►For a listing of chemicals which cannot be stored in or near the boiler room, please see subsection entitled "Mechanical room" in the "Installation Instructions".



■ Advice to owner

Once the installation work is complete, the heating contractor must familiarize the system operator/ultimate owner with all equipment, as well as safety precautions/requirements, shutdown procedure, and the need for professional service annually before the heating season begins.



WARNING

Installers must follow local regulations with respect to installation of carbon monoxide detectors. Follow the Viessmann maintenance schedule of the boiler contained in this manual.

Operating and Service Documentation

It is recommended that all product documentation such as parts lists, operating and service instructions be handed over to the system user for storage. Documentation is to be stored near boiler in a readily accessible location for reference by service personnel.

■ Carbon monoxide

Improper installation, adjustment, service and/or maintenance can cause flue products to flow into living space. Flue products contain poisonous carbon monoxide gas.


►For information pertaining to the proper installation, adjustment, service and maintenance of this equipment to avoid formation of carbon monoxide, please see subsection entitled "Mechanical room" and "Venting requirements" in the "Venting System Installation Instructions".



■ Fresh air

This equipment requires fresh air for safe operation and must be installed ensuring provisions for adequate combustion and ventilation air exist.

►For information pertaining to the fresh air requirements of this product, please see subsection entitled "Mechanical room" in the "Installation Instructions".



■ Equipment venting

Never operate boiler without an installed venting system. An improper venting system can cause carbon monoxide poisoning.

►For information pertaining to venting and chimney requirements, please see section entitled "Venting Connection". All products of combustion must be safely vented to the outdoors.



WARNING

This boiler requires fresh air for safe operation and must be installed with provisions for adequate combustion and ventilation air (in accordance with local codes and regulations of authorities having jurisdiction).

Do not operate this boiler in areas with contaminated combustion air. High levels of contaminants such as dust, lint or chemicals can be found at construction sites, home renovations, in garages, workshops, in dry cleaning/laundry facilities, near swimming pools and in manufacturing facilities.

Contaminated combustion air will damage the boiler and may lead to substantial property damage, severe personal injury and/or loss of life. Ensure boiler/burner is inspected and serviced by a qualified heating contractor at least once a year in accordance with the Service Instructions of the boiler.

Safety, Installation and Warranty Requirements *(continued)*

Fiberglass wool and ceramic fiber materials



WARNING

Inhaling of fiberglass wool and/or ceramic fiber materials is a possible cancer hazard. These materials can also cause respiratory, skin and eye irritation.

The state of California has listed the airborne fibers of these materials as a possible cancer hazard through inhalation. When handling these materials, special care must be applied.

Suppliers of ceramic fiber products recommend the following first aid measures:

- Respiratory tract (nose and throat) irritation:
If respiratory tract irritation develops, move the person to a dust free location.
- Eye irritation: If eyes become irritated, flush immediately with large amounts of lukewarm water for at least 15 minutes. Eyelids should be held away from the eyeball to ensure thorough rinsing. Do not rub eyes.
- Skin irritation: If skin becomes irritated, remove soiled clothing. Do not rub or scratch exposed skin. Wash area of contact thoroughly with soap and water. Using a skin cream or lotion after washing may be helpful.
- Gastrointestinal irritation: If gastrointestinal tract irritation develops, move the person to a dust free environment.

Suppliers of fiberglass wool products recommend the following precautions be taken when handling these materials:

- Avoid breathing fiberglass dust and contact with skin and eyes.
- Use NIOSH approved dust/mist respirator.
- Wear long-sleeved, loose fitting clothing, gloves and eye protection.
- Wash work clothes separately from other clothing. Rinse washer thoroughly.
- Operations such as sawing, blowing, tear-out and spraying may generate airborne fiber concentration requiring additional protection.

First aid measures

- If eye contact occurs, flush eyes with water to remove dust. If symptoms persist, seek medical attention.
- If skin contact occurs, wash affected areas gently with soap and warm water after handling.



WARNING

Appliance materials of construction, products of combustion and the fuel contain alumina, silica, heavy metals, carbon monoxide, nitrogen oxides, aldehydes and/or other toxic or harmful substances which can cause serious injury or loss of life and which are known to the State of California to cause cancer, birth defects and other reproductive harm. Always use proper safety clothing, respirators and equipment when servicing or working nearby the appliance.

About these Service Instructions



Take note of all symbols and notations intended to draw attention to potential hazards or important product information. These include "WARNING", "CAUTION", and "IMPORTANT". See below.



WARNING

Indicates an imminently hazardous situation which, if not avoided, could result in loss of life, serious injury or substantial product/property damage.

- Warnings draw your attention to the presence of potential hazards or important product information.



CAUTION

Indicates an imminently hazardous situation which, if not avoided, may result in minor injury or product/property damage.

- Cautions draw your attention to the presence of potential hazards or important product information.

IMPORTANT

- Helpful hints for installation, operation or maintenance which pertain to the product.

- This symbol indicates that additional, pertinent information is to be found.

- This symbol indicates that other instructions must be referenced.

Page

Safety

| | |
|------------------------------------------------------------|----------|
| Safety, Installation and Warranty Requirements..... | 2 |
| Product documentation..... | 2 |
| Warranty..... | 2 |
| Licensed professional heating contractor..... | 2 |
| Contaminated air..... | 2 |
| Advice to owner..... | 2 |
| Operating and Service Documentation..... | 2 |
| Carbon monoxide..... | 2 |
| Fresh air..... | 2 |
| Equipment venting..... | 2 |
| Fiberglass wool and ceramic fiber materials..... | 3 |
| First aid measures..... | 3 |
| About the Service Instructions..... | 3 |

General Information

| | |
|----------------------------------------------------------------|----------|
| Necessary Tools..... | 6 |
| Important Regulatory and Installation Requirements..... | 6 |
| Codes..... | 6 |
| Technical literature..... | 6 |
| Initial start-up..... | 6 |
| Working on the equipment..... | 6 |
| Instructing the system user..... | 6 |
| CSD-1 Field Testing of High Limit Switches..... | 7 |
| Applicability..... | 8 |
| Product Information..... | 8 |
| Mechanical Room..... | 9 |

Start-up

| | |
|----------------------------------------------------------------|-----------|
| Filling the Heating System..... | 10 |
| Removing the Front Panels..... | 11 |
| Filling Siphon With Water..... | 11 |
| Opening the Control Unit..... | 12 |
| Check Power Supply Connection..... | 12 |
| Start-up Wizard..... | 13 |
| Select language..... | 13 |
| Set time and date..... | 13 |
| Select temperature unit..... | 13 |
| Set DHW temperature setpoint..... | 13 |
| Selecting zone circuits..... | 14 |
| Selecting zone circuit type..... | 14 |
| Select fixed setpoint..... | 14 |
| Adjust heating curve..... | 14 |
| Select pump output..... | 15 |
| Confirm pump output..... | 15 |
| Zone circuit temperature setting..... | 15 |
| Weather compensated operation..... | 15 |
| Designating Heating Circuits..... | 16 |
| Setting High Altitude..... | 16 |
| Select Gas Type..... | 17 |
| Convert Fuel Type to LPG..... | 17 |
| Measuring the Static Pressure and Running Pressure..... | 18 |
| Set Maximum Output..... | 19 |
| Check All Primary and Secondary Circuit | |
| Connections for Leaks..... | 19 |
| Check Gas Pipes and Fittings for Leaks..... | 19 |
| Perform Combustion Analysis..... | 20 |
| Checking the Direct Vent (coaxial) System Tightness..... | 20 |
| Sequence of Operation and Potential Faults During | |
| Each Start-up Cycle..... | 21 |

| | Page |
|--------------------------------------------------------------------------|------|
| Service | |
| Removing the Burner and Checking the Burner Gasket... | 22 |
| Placing the Burner Door in the Service Retainer..... | 22 |
| Checking Burner Mesh Assembly and Refractory..... | 23 |
| Check and Adjust Ignition and Ionization Electrodes..... | 23 |
| Cleaning the Combustion Chamber and Heating Surfaces.. | 24 |
| Separating the Neutralizing System (if installed)..... | 24 |
| Cleaning and Reconnecting the Condensate Drain System.. | 25 |
| Checking Gaskets and Thermal Insulation Components on the Boiler..... | 26 |
| Checking the Diaphragm Expansion Vessel and System Pressure..... | 26 |
| Fitting the Burner..... | 27 |
| Clock Natural Gas Meter..... | 27 |
| Check CO ₂ Setting..... | 28 |
| Combustion Management System..... | 29 |
| Check Functioning Safety Valves..... | 29 |
| Check Electrical Connections..... | 30 |
| Check Gas Pipes and Fitting for Leaks..... | 30 |
| Check the Mixing Valve for Obstructions and Leaks..... | 30 |
| Example Layout 1..... | 31 |
| Example Layout 2..... | 35 |
| Example Layout 3..... | 40 |
| Example Layout 4..... | 45 |
| Start-up..... | 46 |
| Menu Heating Circuits..... | 47 |
| Functional Description..... | 49 |
| Adjusting the Heating Curves..... | 50 |
| Connecting the Boiler to the LON System..... | 53 |
| Coding 1 | |
| General..... | 55 |
| Boiler..... | 56 |
| DHW..... | 57 |
| Solar..... | 57 |
| Heating Circuit 1, 2 and 3..... | 58 |
| Coding 2 | |
| General | 62 |
| Boiler..... | 69 |
| DHW..... | 70 |
| Solar..... | 72 |
| Heating Circuit 1, 2 and 3..... | 76 |
| Zone Heating Circuit 1, 2 and 3..... | 81 |
| Diagnosis and Service Scans | |
| Calling up the Service Level..... | 82 |
| Diagnosis..... | 83 |
| Troubleshooting | |
| Checking Outputs (relay tests)..... | 84 |
| Fault Codes..... | 85 |
| Corrective Action..... | 93 |
| Function Description | |
| Internal Extensions EA1..... | 98 |
| Control Functions..... | 100 |
| Additional Information | |
| Wiring Diagram..... | 101 |
| Fitting the Front Panel..... | 103 |
| Burner Program Sequence of Operation..... | 104 |
| Parts Lists..... | 105 |
| Installation Fittings..... | 110 |
| Technical Data..... | 111 |
| Maintenance Record..... | 113 |
| Lighting and Operating Instructions..... | 114 |

Necessary Tools

Testing/analysis equipment (Use only calibrated equipment)

- Multimeter to measure 0 - 230V, 0 - 12A AC and 0-100 mA DC
- Flue gas analyzer to measure % CO₂ or O₂ (i.e. Bacharach fluid samplers or suitable electronic analyzer)
- Manometer to measure gas pressure 0 to 11 "w.c. (accurately) and up to 28 "w.c. gas pressure (or a non-electric Magnehelic® manometer may also be utilized)
- Stack thermometer 0°F to 500°F (0°C to 260°C)
- Bacharach calculator or suitable tables to calculate efficiency
- Carbon monoxide measuring equipment 0 to 400 ppm

Cleaning supplies

- Plastic hand brush
- Rags

Special items

- Approved leak detection fluid for natural gas and liquid propane gas
- Pipe joint sealant

Important Regulatory and Installation Requirements

Codes

The installation of this unit shall be in accordance with local codes or, in the absence of local codes, use CAN/CSA-B149.1 or .2 Installation Codes for Gas Burning Appliances for Canada. For U.S. installations use the National Fuel Gas Code ANSI Z223.1. Always use latest editions of codes.

In Canada all electrical wiring is to be done in accordance with the latest edition of CSA C22.1 Part 1 and/or local codes. In the U.S. use the National Electrical Code ANSI/NFPA 70. The heating contractor must also comply with both the Standard for Controls and Safety Devices for Automatically Fired Boilers, ANSI/ASME CSD-1, and the Installation Code for Hydronic Heating Systems, CSA B214, where required by the authority having jurisdiction.

Technical literature

Literature for the Vitocrossal 300 CU3A boiler:

- Technical Data Manual
- Installation Instructions
- Service Instructions
- Operating Instructions and User's Information Manual
- Instructions of other Viessmann products utilized and installed
- Installation codes mentioned in this manual

Leave all literature at the installation site and advise the system operator/ultimate owner where the literature can be found. Contact Viessmann for additional copies.

This product comes with several safety instruction labels attached. Do not remove! Contact Viessmann immediately if replacement labels are required.

Initial start-up

Initial start-up must be performed by a qualified heating contractor. Proper completion of the Maintenance Record by the heating contractor is also required. The Maintenance Record is located in the Service Instructions.

Carbon Monoxide Detectors

The installer must verify that at least one carbon monoxide alarm has been installed within a residential living space or home following the alarm manufacturer's instructions and applicable codes before putting the appliance into operation.

Working on the equipment

The installation, adjustment, service, and maintenance of this boiler must be done by a licensed professional heating contractor who is qualified and experienced in the installation, service, and maintenance of hot water boilers. There are no user serviceable parts on the boiler, burners, or control.

Please carefully read this manual prior to attempting start-up, maintenance or service. Any warranty is null and void if these instructions are not followed.

For information regarding other Viessmann System Technology componentry, please reference documentation of the respective product.

We offer frequent installation and service seminars to familiarize our partners with our products. Please inquire.

Ensure main power supply to equipment, the heating system, and all external controls has been deactivated. Close main gas supply valve. Take precautions in all instances to avoid accidental activation of power during service work.

The completeness and functionality of field supplied electrical controls and components must be verified by the heating contractor. These include low water cut-offs, flow switches (if used), staging controls, pumps, motorized valves, air vents, thermostats, etc.

Instructing the system user

The installer of the system is responsible to ensure the system operator/ultimate owner is made familiar with the system functioning, its activation, and its shut-down.

The following topics must be covered:

- Proper system operation sequence.
- Explain the equipment.
- Demonstrate an emergency shut-down, what to do and what not.
- Explain that there is no substitute for proper maintenance to help ensure safe operation.

Important Regulatory and Installation Requirements *(continued)***CSD-1 Field Testing of High Limit Switches for Vitocrossal 300 CU3A boilers – where required by law.**

VISSMANN IS NOT RESPONSIBLE FOR ANY DAMAGES THAT THE FOLLOWING TEST PROCEDURE MAY RESULT IN BY OVERHEATING THE SYSTEM.

The fixed high limit, when tripped, produces a fault that will require manual reset of the boiler control.

Fixed High Limit fault simulation:

- Run the boiler to high fire via relays test.
- Throttle the boiler valve to a point where the burner will run with as little flow as possible.
- When the burner shuts down on the electronic limit, close the ball valve to stop the flow.
- The boiler temperature should continue a steady increase to trip the fixed high limit.
- Once the fixed high limit is tripped, slowly open the boiler valve to safely cool the boiler down.

Applicability



CAUTION

The boiler serial number must be provided when ordering replacement parts.

IMPORTANT

When ordering replacement parts, provide the 16-digit boiler serial number (on the bar code label), located as shown underneath boiler front enclosure panel. Refer to page 11 for instructions on how to remove front enclosure panel.

Model No. CU3A 26, 94

Serial No. 7553000

Model No. CU3A 35, 125

Serial No. 7553001

Model No. CU3A 45, 160


Serial No. 7553002

Model No. CU3A 57, 199

Serial No. 7553003

Legend

- Ⓐ Digital Vitotronic boiler control unit
- Ⓑ Water-cooled stainless steel combustion chamber
- Ⓒ Modulating MatriX gas burner – for extremely clean combustion
- Ⓓ Stainless steel Inox-Crossal heat exchanger
- Ⓔ Highly effective thermal insulation
- Ⓕ Flue gas collector with condensate drain pipe
- Ⓖ Combustion air intake for direct vent (two-pipe) systems



Product Information

Natural gas and liquid propane gas-fired condensing heating boiler for weather-responsive operation in closed loop, forced circulation hot water heating systems for space heating and domestic hot water (DHW) production.

The Vitocrossal 300 CU3A boiler comes factory set for operation with natural gas. For a fuel conversion to liquid propane gas no conversion kit is required.

Boiler model must be selected based on an accurate heat loss calculation of the building. Ensure boiler model is compatible with connected radiation.

Vitocrossal 300 CU3A boilers are factory-tested and calibrated. Further gas valve adjustments are not typically required during field start-up.



Follow the Vitocrossal 300 CU3A Venting System Installation Instructions to vent this boiler.

Mechanical Room

During the early stages of designing a new home, we recommend that proper consideration be given to constructing a separate mechanical room dedicated to the gas- or oil-fired heating equipment and domestic hot water storage tank(s).

The boiler must be located in a heated indoor area, near a floor drain, and as close as possible to a wall. Whenever possible, install the boiler near an outside wall so that it is easy to duct the venting system to the boiler.

Ensure that the boiler location does not interfere with the proper circulation of combustion and ventilation air of other fuel burning equipment within the mechanical room (if applicable).

The maximum room temperature of the mechanical room where the boiler is located must not exceed 104°F (40°C).

Installation area conditions



WARNING

Incorrect ambient conditions can lead to damage to the heating system and put safe operation at risk.

- Ensure ambient temperatures are higher than 32°F (0°C) and lower than 104°F (40°C).
- Prevent the air from becoming contaminated by halogenated hydrocarbons (e.g. as contained in paint solvents or cleaning fluids) and excessive dust (e.g. through grinding or polishing work). Combustion air for the heating process, and ventilation of the boiler room must be free of corrosive contaminants. To that end, any boiler must be installed in an area that has no chemical exposure. The list to the right indicates the main, currently known sources.
- Avoid continuously high levels of humidity (e.g. through frequent drying of laundry).
- Never close existing ventilation openings.



WARNING

If you notice fire coming from the appliance, call the fire department immediately! Do not attempt to extinguish the fire unless qualified to do so.

IMPORTANT

The service life of the boiler's exposed metallic surfaces, such as the casing and fan housing, is directly influenced by proximity to damp and salty marine environments. In such areas, higher concentration levels of chlorides from sea spray, coupled with relative humidity, can lead to degradation of the exposed metallic surfaces mentioned above. Therefore, it is imperative that boilers installed in such environments not be installed using direct vent systems which draw outdoor air for combustion. Such boilers must be installed using room air dependent vent systems; i.e. using room air for combustion. The indoor air will have a much lower relative humidity and, hence, potential corrosion will be minimized.

Sources of combustion and ventilation air contaminants Areas likely to contain contaminants:

- New building construction
- Swimming pools
- Remodelling areas, hobby rooms
- Garages with workshops
- Furniture refinishing areas
- Dry cleaning/laundry areas and establishments
- Auto body shops
- Refrigeration repair shops
- Metal fabrication plants
- Plastic manufacturing plants
- Photo processing plants
- Beauty salons

Products containing contaminants:

- Chlorine-type bleaches, detergents and cleaning solvents found in household laundry rooms
- Paint and varnish removers
- Hydrochloric acid, muriatic acid
- Chlorine-based swimming pool chemicals
- Spray cans containing chlorofluorocarbons
- Chlorinated waxes and cleaners
- Cements and glues
- Refrigerant leaks
- Calcium chloride used for thawing
- Sodium chloride used for water softening salt
- Permanent wave solutions
- Adhesives used to fasten building products and other similar items
- Antistatic fabric softeners used in clothes dryers

Boiler operation in marine environments (damp, salty coastal areas)




WARNING

Fire causes a risk of burns and explosion!

- Shut down the boiler
- Close fuel shut-off valves
- Use a tested fire extinguisher, class ABC.

Filling the Heating System



CAUTION

Unsuitable fill water increases the level of deposits and corrosion, and may lead to damage to the equipment.

- Thoroughly flush the entire heating system prior to filling with water.
- Only use water of potable quality.
- The water will have to be softened if it is harder than 8.77 grains / 150 ppm total dissolved solids.
- Inhibitors or antifreeze additives suitable for heating systems may be added manually.

1. Check the pre-charge pressure of the diaphragm expansion vessel when the system is still cold.

Note: If the pre-charge pressure of the diaphragm expansion vessel is lower than the static pressure of the system, top up with nitrogen until the precharge pressure 1.5 to 3 psi (0.1 to 0.2 bar) is higher than the static system pressure. The static pressure corresponds to the static head.

2. Close the gas shutoff valve.

3. Open any installed shutoff valves.

4. Fill the heating system with water and vent it, until the fill pressure 1.5 to 3 psi (0.1 to 0.2 bar) is higher than the pre-charge pressure of the diaphragm expansion vessel using the boiler drain/fill valve (A).

Max. operating pressure: 30 psi (2 bar)

Min. operating pressure: 14 psi (1 bar)


Pressure relief valve: 30 psi (2 bar)

5. Mark the set pressure at temperature and pressure gauge (B).

6. Return the shutoff valves to their operating position.


7. Close boiler drain/fill valve (A).

Removing the Front Panel




1. Remove the retaining screw and set aside.
2. Pull the top of the boiler cover away from the boiler, lift off and set aside.

Filling Siphon with Water



1. Undo fitting (A) of siphon (B), remove the siphon and fill it with water.
Note: There is a risk of flue gas escaping if the siphon is not filled with water.
2. Refit siphon (B).

Opening the Control Unit



Legend

- Ⓐ Top part of control unit with programming unit
- Ⓑ Push button for changing the angle
- Ⓒ On/off switch

Vitotronic 200, type KW6B

1. Lift the programming unit Ⓐ into the upright position (the angle of the programming unit can be adjusted using the push button on the side Ⓑ).
2. Open the control cover and turn the boiler on by switching the on/off switch Ⓒ.

Check Power Supply Connection

An external accessories connection modules are integrated into the Vitocrossal 300 CU3A boiler, which requires a 120VAC power supply from a wall receptacle (15A fuse protected).

Refer to the Installation Instructions shipped with the boiler.

Voltage range

The voltage at connector **40** of the boiler control must be 120V (see wiring diagram).

Neutral conductor

The electrical power supply must have a neutral conductor.

IMPORTANT

In Canada all electrical wiring is to be done in accordance with the latest edition of CSA C22.1 Part 1 and/or local codes. In the U.S. use the National Electrical Code ANSI/NFPA 70. The heating contractor must also comply with both the Standard for Controls and Safety Devices for Automatically Fired Boilers, ANSI/ASME CSD-1.

Note: The line conductor "L" and the neutral conductor "N" must not be interchanged.

See wiring diagram on page 101 in section entitled "Additional Information".


Start-up Wizard



Select Language


At the commissioning stage, the display is in German.

1. "Sprache" (Language) Deutsch DE (German)
2. Select the required language with ▲/▼
3. Accept by pressing OK




Set time and date

1. Using the ▲/▼ set the current time
2. Accept by pressing OK, this will move to date
3. Using the ▲/▼ set the current date
4. Press OK to complete



Select temperature unit


1. Select the temperature unit "°C" or "°F" using the ▲/▼
2. Accept by pressing OK



Set DHW temperature setpoint

1. Set DHW temperature setpoint with ▲/▼
2. Accept by pressing OK


Note: if the DHW sensor is installed.




Select zone circuits

During the start-up wizard an additional display screen will come up asking for the number of connected zone circuits use ▲/▼ to adjust and press OK.


If no zone circuit is selected the control will finish the set up and display will show DHW/Heating circuit 1, outdoor temperature, indoor temperature setup and burner operating status.

Start-up Wizard *(continued)***Select zone circuit type**


Each zone circuit can be operated either as a fixed setpoint or weather compensated (using the outdoor temperature sensor) thermostat, use ▲/▼ to select and press OK.

**Select fixed setpoint**


For zone circuits with fixed setpoint operation select desired supply water temperature use ▲/▼ to adjust and press OK.

**Adjust heating curve**


Select between slope and shift with ▲/▼ and ►/◄ to adjust and press OK.

**Select pump output**

Assign desired pump output for zone circuit with ▲/▼ and press OK.

Start-up Wizard *(continued)***Confirm pump output**

Confirmation of selected pump output and press OK.

**Zone circuit temperature setting**

For the selected zone with fixed set point thermostat will display zone circuit temperature setting.

**Weather compensated operation**

For the selected zone circuit with weather compensated operation the current outdoor temperature and the current setpoint boiler temperature as calculated by the outdoor reset curve.

Making changes using the start-up wizard

In the event that an error has been made in the initial set-up of the start-up wizard or additional system components have been added to the system, the start-up wizard can be restarted at any time by;

1. Press OK and 'menu' simultaneously for approximately 4 sec.
2. "Service Functions"
3. "Set-up Wizard"
4. ▲/▼ to select 'Yes'
5. Press OK and the start-up wizard will restart

It is recommended the settings are recorded prior to restarting the start-up wizard as some settings may be reset during this process.

Designating Heating Circuits

In the delivered condition, the heating circuits are designated "Heating circuit 1", "Heating circuit 2" and "Heating circuit 3" (if installed).

If the system user prefers, the heating circuits can be designated differently to suit the specific system.

To enter names for heating circuits:



Refer to the Operating Instructions

Setting High Altitude

In the factory default setting, the boiler is equipped to operate in altitudes of up to 5,000 ft. (1,500 m).

Altitude can be set using coding address 93:

(in coding level 2 General).

- Coding 11:9 must be set in order to unlock coding 93:.
- 93:0 is reserved for altitudes up to 5000 ft. (1500 m).
- 93:6 must be set for altitudes from 5000 ft. (1500 m) to 10000 ft. (3000 m)
- Setting back to 93:0 turns off the high altitude function.

IMPORTANT

Do not set or use coding addresses 93:1 to 93:5.

- After setting coding address 93:, set coding address 11:0
- The program is automatically disabled after 20 minutes.

Select Gas Type


Note: the Vitocrossal 300 CU3A boiler is factory set to operate with natural gas . See following subsection for conversion instructions to liquid propane gas.

1. Ensure that the fuel type listed on the boiler rating plate is the correct type for the installation being attempted.
2. Record fuel type in Maintenance Record on page 113.

The Vitocrossal 300 CU3A boiler is for use with gases whose characteristics fall within the following ranges. Do not use any other types of gas.

| | | Natural gas | Liquid propane gas |
|--------------------------------------------|---------------------|--------------|--------------------|
| Heating value (gross) | Btu/ft ³ | 970 to 1100 | 2466 to 2542 |
| Specific gravity | | 0.57 to 0.70 | 1.522 to 1.574 |
| Ultimate carbon dioxide (CO ₂) | % | 11.7 to 12.2 | 13.73 to 13.82 |

Convert Fuel Type to LPG



Gas type conversion


1. Set adjusting screw (A) on the gas valve to "2".
2. Turn ON/OFF switch "ⓘ" ON.
3. Select the gas type in coding address "82".
 - Call up code 2.
 - "General"
 - In coding address "11", select value "9".
 - In coding address "82", select value "1" (LPG operation).
 - Set code "11" value unequal "9".
 - End service functions.
4. Open the gas shut-off valve
5. Affix fuel conversion label supplied with the fuel conversion kit as shown in the fuel conversion kit instructions.



! WARNING

Hot surfaces can cause burns
DO NOT TOUCH!
Allow to cool before servicing

Measure Static Pressure and Running Pressure



1. To measure static and/or running pressure remove boiler enclosure panel as indicated page 11 in these instructions.
2. Close gas shutoff valve (field supplied).
3. Loosen screw at inlet gas pressure port (A) on the gas combination valve, do not remove completely. Connect manometer.
4. Open the gas shutoff valve.
5. Measure static pressure. Values must be:
14 "w.c. maximum for NG
14 "w.c. maximum for LPG
6. Enter measured value into Maintenance Record on page 113 in this manual.
7. Start up boiler, using the ON/OFF switch "ⓘ" on the boiler control.
Note: Flip up lower orange cover to access the ON/OFF switch.
8. Measure the running pressure; value must be:
Note: Use suitable measuring instruments calibrated with a minimum resolution of 0.04 "w.c. for measuring the running pressure.

IMPORTANT

A CO₂ measurement (see page 28) must be taken before and after working on gas appliances to eliminate risks to health and to guarantee the satisfactory condition of the system.

IMPORTANT

The burner is automatically ignited and starts operation after a safety time has elapsed. During initial start-up, the unit may indicate a fault because of air in the gas supply pipe (especially for liquid propane gas). After approx. 5 seconds, press the "R" button to reset the burner. The ignition procedure is repeated. This boiler employs a direct spark ignition system.

⚠ WARNING

Ensure that there is no open flame in the room.



⚠ WARNING

Hot surfaces can cause burns
DO NOT TOUCH!
Allow to cool before servicing

| Running supply pressure with | | Corrective action |
|------------------------------|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NG | LPG | |
| under 4 "w.c. | under 4 "w.c. | Do not start the boiler. Notify your gas supply utility or LPG supplier. |
| 4 to 14 "w.c. | 10 to 14 "w.c. | Start up boiler. |
| over 14 "w.c. | over 14 "w.c. | Do not attempt adjustment. Call local gas utility to decrease pressure or install up stream gas pressure regulator. Boiler valve must not be exposed to pressure over 14 "w.c. |


9. Enter gas type into Maintenance Record on page 113 in this manual.
10. Switch off the ON/OFF switch "ⓘ" on the boiler control, close the gas shut-off valve, remove the manometer and re-tighten the screw at inlet gas pressure port (A).

⚠ WARNING

Never purge a gas line into a combustion chamber. Never use matches, candles, flame, or other sources of ignition for purpose of checking leakage. Use a soap and water solution to check for leakage. A failure to follow this warning could result in fire, explosion, personal injury or death.

Setting the Maximum Output

You can limit the maximum output for heating operation. The limit is set via the modulation range. The max. adjustable output is limited upwards by the boiler coding card.

1. Press OK and  simultaneously for approx. 4 sec.
2. "Service functions"
3. "Max. output"
4. "Change?" Select "Yes". A value flashes on the display (e.g. "85"). In the delivered condition, this value represents 100% of rated output.
5. Set the required value.

Check All Primary and Secondary Circuit Connections for Leaks

| | |
|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
|  | <p>! WARNING</p> <p>Hot surfaces can cause burns DO NOT TOUCH! Allow to cool before servicing</p> |
|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|

Check heating system and domestic hot water connections (if applicable). Ensure all connections are pressure tight. Correct any leaks found on fittings, pumps, valves, etc.

Check Gas Pipes and Fittings for Leaks

| | |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
|  | <p>! WARNING</p> <p>Hot surfaces can cause burns DO NOT TOUCH! Allow to cool before servicing</p> |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|


Note: For the tightness test, use only suitable and approved leak detecting agents and devices. Leak detecting agents with unsuitable contents (e.g. nitrites, sulphides) can lead to material damage. Remove residues of the leak detecting agent after testing.

| |
|------------------------------------------------------------------------------------------------------------------|
| <p>! WARNING</p> <p>Escaping gas leads to a risk of explosion. Check gas equipment for tightness.</p> |
|------------------------------------------------------------------------------------------------------------------|

| |
|------------------------------------------------------------------------------------------------------------------|
| <p>! WARNING</p> <p>The gas supply piping must be leak tested before placing the boiler in operation.</p> |
|------------------------------------------------------------------------------------------------------------------|

| |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>! CAUTION</p> <p>Ensure all joints of gas line are pressure tight and that gas valves do not leak when under normal operating pressure (use approved leak detection liquid).</p> |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Perform Combustion Analysis



Legend

Ⓐ Flue gas test port

IMPORTANT

A CO₂ measurement (see page 28) must be taken before and after working on gas appliances to eliminate risks to health and to guarantee the satisfactory condition of the system.


Record the measured combustion values in the sequence stated in the Maintenance Record on page 113 in this manual.



! WARNING

Hot surfaces can cause burns
DO NOT TOUCH!
Allow to cool before servicing

Checking the Direct Vent (coaxial) System Tightness



Legend

Ⓐ Air inlet flapper

Viessmann strongly recommends that the heating contractor perform a simplified leak test during boiler start-up. For this purpose it is sufficient to measure the CO₂ concentration of the combustion air in the coaxial gap of the air intake adaptor. The vent pipe is considered sufficiently leak-proof if a CO₂ concentration in the combustion air no higher than 0.2% or an O₂ concentration no lower than 20.6% is measured. If higher CO₂ values or lower O₂ values are measured, check venting system thoroughly.

Note: This measurement can be taken at the flapper Ⓐ located on the air inlet pipe located just prior to the burner.




! WARNING

Hot surfaces can cause burns
DO NOT TOUCH!
Allow to cool before servicing


Sequence of Operation and Potential Faults During Each Start-up Cycle

Function sequence and possible faults



For further details on faults, see page 86.

Removing the Burner and Checking the Burner Gasket



1. Switch OFF the main power supply and the ON/OFF switch at the control unit.
2. Close the gas shut-off valve and safeguard against reopening.
3. Pull power cables from fan motor (H), gas valve (C) and ionization electrode (D). Pull plug (G).
4. Undo fitting on gas supply pipe (E) and pull air intake adaptor (A).
5. Undo four nuts (B) and remove burner (F), then hook it into its service retainer (L).
Note: Prevent damage to the burner. Always hook the burner into its service retainer.
6. Check burner gasket (K) for possible damage; replace if necessary. The burner gasket should be replaced every 2 years.



CAUTION


To avoid damage to the burner, do not lay burner on its dome matrix or touch the burner mesh.
Failure to heed this caution may cause damage to the burner, which may lead to improper operation.



WARNING

Hot surfaces can cause burns
DO NOT TOUCH!
Allow to cool before servicing


Placing the Burner Door in the Service Retainer



WARNING

Hot surfaces can cause burns
DO NOT TOUCH!
Allow to cool before servicing

Checking Burner Mesh Assembly and Refractory




Replace the burner mesh assembly if the wire mesh is damaged.

1. Remove electrodes (A).
2. Undo four nuts (D) and remove fan with gas valve (C).
3. Release three nuts (B) and remove burner mesh assembly (H).
4. Remove refractory (F) with thermal insulating mat (E).
5. Remove old burner mesh assembly gasket (G).
6. Check refractory (F) for damage and replace, if required.
7. Insert thermal insulating mat (E) and refractory (F) according to the electrode position.
Note: Observe the positioning aid on the refractory.
8. Insert new burner mesh assembly (H) with new gasket (G) and secure with three nuts.
Torque: 3.7 lb.ft (5 Nm).
9. Fit the fan with the gas valve. Torque: 3.7 lb.ft (5 Nm).




Checking and Adjust the Ignition and Ionization Electrodes



Legend

- (A) Ignition electrodes
- (B) Ionization electrode
- (C) Up to 35 kW (125 MBH)
- (D) From 45 kW (160 MBH)

1. Check the electrodes for wear and contamination.
2. Clean the electrodes with a small brush (not with a wire brush) or sandpaper.



3. Check the electrode gaps. If the gaps are not as specified or the electrodes are damaged, replace and align the electrodes together with new gaskets. Tighten the electrode fixing screws with a torque of 2.2 lb.ft (3.0 Nm).



Cleaning the Combustion Chamber and Heating Surfaces

WARNING

Follow cleaning agent manufacturer's safety instructions and wear appropriate protective equipment.

WARNING

Never use a metal wire brush or mechanically driven brushes.



WARNING


Hot surfaces can cause burns
DO NOT TOUCH!
Allow to cool before servicing

1. Remove burner assembly as per instruction on page 22.
2. Clean the combustion chamber by vacuuming loose debris out.
3. Remove embedded sediment from the heat exchanger surface by thoroughly rinsing with water or solvent free cleaning agents such as citric acid based cleaners. Avoid getting the refractory wet during cleaning.
Note: Discoloration of the heat exchanger surface is the normal result of the combustion process. It has no impact on the functionality or the longevity of the heat exchanger.
4. Use a non-metallic brush if necessary, with a gentle brushing motion to remove the embedded sediment.
5. Flush the combustion chamber with water until it runs clear through the condensate trap.
6. Remove and clean out any accumulated debris from condensate trap. Reinstall condensate trap. See page 25 for details.
7. Mount burner and tighten diagonally to a torque of 3 lb.ft. (4 Nm).
8. Fit gas supply pipe with new gasket. Torque: 11 lb.ft (15 Nm).
9. Plug in air intake adaptor.
10. Connect the electrical cables/leads to the corresponding components.

IMPORTANT

Perform gas leak test.

Separating the Neutralizing System (if installed)



Separating the neutralizing system (if installed) from the boiler and connecting the drain hose


1. Separate the hose to the neutralizing system from siphon (A).



WARNING

Hot surfaces can cause burns
DO NOT TOUCH!
Allow to cool before servicing

Cleaning and Reconnecting the Condensate Drain System





! WARNING

Hot surfaces can cause burns
DO NOT TOUCH!
Allow to cool before servicing

Flue collector, condensate drain, siphon, neutralizing system and all hoses or pipe runs in between are considered part of the condensate drain system.

Note: Clean the inside of the condensate drain system at least annually.

1. Undo fitting (A) on the siphon (B) and remove the siphon from the boiler.
2. Clean the inside of inlet connector (D) with a brush.
3. Remove bottom part (C) of siphon (B), then clean and refit it.
4. Fill siphon (B) with water and refit with inlet connector (D).

Note: There is a risk of flue gas escaping if the siphon is not filled with water.

5. Clean the insides of the condensate drain system and the neutralizing system (if installed).
6. Check the pH value of the condensate with pH measuring strip. If the pH value is less than 6.5, replace granulate.
7. If contaminated:
Rinse neutralization unit with tap water.
8. Add granulate as marked.



Refer to the Neutralization Unit
Installation Instructions (if applicable)

9. Undo drain hose to the building drain from siphon (B).
10. Reconnect the neutralizing system to the siphon (B).

IMPORTANT

pH measuring strip must be field supplied.

IMPORTANT


The granulate is consumed as it neutralizes the condensate. For minimum granulate level, refer to the neutralization unit Operating Instructions.

Checking that the condensate drain and neutralizing system (if installed) are not obstructed and that they are free from leaks.

Add water to the combustion chamber.

Note: The water must flow from the condensate drain without back pressure. If necessary, clean the condensate drain again.

Checking Gaskets and Thermal Insulation Components on the Boiler



1. Check the gasket/seal on the flue gas collector (A) between the flue gas collector (C) and the boiler body (B) for tightness.

2. Check lip seal (D) of the boiler flue connection for tightness.

Note: The seals/gaskets can also be checked under full load with an inspection mirror. If required, remove the thermal insulation components. Traces of condensate on the outside of flue gas collector (C) also point towards a leak.

3. If required, retighten the flue gas collector seal (A) at the tensioning toggles (E) or replace. Replace lip seal (D) in case it leaks.

Note: Prior to removing the flue gas collector, pull the plug at flue gas temperature sensor (F).

4. Check the fittings on the water side for leaks and replace the seals/gaskets if required.



WARNING

There is a risk of injury when working on pressurized components. Only open the connections on the heating water side after the boiler has been depressurized. Only drain the boiler with a suction pump when the boiler air vent valve is open.



WARNING

Hot surfaces can cause burns
DO NOT TOUCH!
Allow to cool before servicing

5. Check the boiler thermal insulation for good fit and correct if required or replace if it is damaged.

Checking the Diaphragm Expansion Vessel and System Pressure



CAUTION


Unsuitable fill water increases the level of deposits and corrosion, and may lead to damage to the equipment.

- Thoroughly flush the entire heating system prior to filling with water.
- Only use water of potable quality.
- The water will have to be softened if it is harder than 8.77 grains / 150 ppm total dissolved solids.
- Inhibitors or antifreeze additives suitable for heating systems may be added manually.

Note: Carry out this test on a cold system.

1. Drain the system or close the cap valve at the diaphragm expansion vessel to depressurize the system until the pressure gauge indicates "0".
2. If the precharge pressure of the diaphragm expansion vessel is lower than the static system pressure, top up with nitrogen until the precharge pressure is raised by 1.5 to 3 psi (0.1 to 0.2 bar).
3. Top up your heating system with water until the filling pressure of a cooled system is 1.5 to 3 psi (0.1 to 0.2) bar higher than the pre-charge pressure of the diaphragm expansion vessel.
Max. operating pressure: 30 psi (2 bar)
Min. operating pressure: 14 psi (1 bar)

Fitting the Burner



1. Insert burner (A) and secure with four nuts (B), tightening the nuts evenly and crosswise.
Torque: 3 lb.ft (4 Nm).
2. Fit gas supply pipe (C) with new gasket (D).
Torque: 11 lb.ft (15 Nm).
3. Plug in ventilation air intake adaptor (E).
4. Connect the electrical cables/leads to the corresponding components.

Checking all gas equipment for tightness at operating pressure.



WARNING

Escaping gas leads to a risk of explosion.
Check gas equipment for tightness.

Note: For the tightness test, use only suitable and approved leak detecting agents and devices. Leak detecting agents containing unsuitable substances (e.g. nitrites, sulphides) can lead to material damage. Remove residues of the leak detecting agent after testing. Refer to page 19 for additional information.

Clock Natural Gas Meter

For example:

A Vitocrossal 300 CU3A 199 boiler (199000 Btu/h max. input) requires 181 sec. to use 10 ft.³ of natural gas. After contacting the local utility, you will find the heating value is 1000 Btu per ft.³.

Therefore:

3,600 sec./h x 10 revolutions
36,000/181 x 1000 = 199000 Btu/h input.
The boiler input is correct.

Burner input formulas (for low altitude only):

INPUT = (3600t) x 1000 where

t = TIME (sec.) for 1 ft.³

INPUT = (3600 x .01 x 1000 x 35.31)T where

T = TIME (sec.) for .01 m³ natural gas

Clock natural gas meter to verify input.

1. Ensure all other gas equipment served by the meter is turned off during timing of gas input to the Vitocrossal 300 CU3A boiler.
2. Measure the time in seconds it takes for the boiler to use 10 ft.³ of gas. Divide 3600 x 10 by the number of seconds and you get the number of ft.³ of gas used per hour. Multiply this number by the heating value of the gas to obtain Btu per hour input.

IMPORTANT

A boiler underfired by 5% is acceptable. Do not overfire the boiler.




CAUTION

Always contact your gas utility to obtain the correct heating value before clocking the meter.

Check CO₂ Setting

The Vitocrossal 300 CU3A boiler is equipped with the Combustion Management System developed by Viessmann which ensures optimal combustion quality independent of gas quality and type. (For a description of the Combustion Management System, see page 29 in this manual). During initial start-up and maintenance you will only need to check the CO₂ and O₂ content at the boiler vent pipe.

Note: The Vitocrossal 300 CU3A boiler comes factory set to operation with natural gas. (For instructions on how to convert to operation with liquid propane gas, see page 17). For high-altitude operation above 5,000 ft. (1,500 m), see page 16. The MatriX burner of this boiler is preset for the entire gas group. No adjustment or readjustment of the burner is required.



1. Connect a flue gas analyzer to test port (A) at boiler vent pipe adaptor.
2. Open gas shut-off valve, start up boiler and create heat demand.
3. Select higher/lower output:
Service menu
- Press OK and simultaneously for approximately 4 seconds.
- "Actuator test"
- Select lower heating output: select "Base load OFF". Then "Base load ON" appears and the burner operates at its upper heating output.
- Select upper heating output: select "Full load OFF". Then "Full load ON" appears and the burner operates at its upper heating output.
- Terminate with OK or .
4. Measure CO₂ and O₂ content at boiler vent pipe. If the measured values deviated by more than 1% from the ranges for the respective fuel type listed in the right column or in the table on page 29.
- check the venting system for leaks (see subsection on page 20).
- check that the boiler is set for the gas type used (see subsection on page 17).
CO₂ content range:
- 7.6 to 11.0% for natural gas
- 9.0 to 11.3% for LPG
O₂ content range:
- 3.8 to 7.3% for all gas types
5. Enter measured values into the Maintenance Record on page 113.
6. Select the upper output: Select "Full load ON". Confirm with OK.
7. Measure CO₂ and O₂ content at boiler vent pipe adaptor. If the measured values deviated by more than 1% from the ranges listed in the right column or in the table on page 29.
- check the venting system for leaks (see subsection on page 20).
- check that the boiler is set for the gas type used (see subsection on page 17).
CO₂ content range:
- 7.6 to 11.0% for natural gas
- 9.0 to 11.3% for LPG
O₂ content range:
- 3.8 to 7.3% for all gas types
8. Press **OK** and after testing and enter measured values into the Maintenance Record on page 113.

Combustion Management System

The combustion management system utilizes the physical correlation between the level of the ionization current and the air factor λ . For all gas qualities, the maximum ionization current results with air factor λ .

The ionization signal is evaluated by the combustion management system, and the air factor is adjusted to between $\lambda = 1.24$ and 1.44 . This range provides for an optimum combustion quality. Thereafter, the electronic gas valve regulates the required gas volume based on the prevailing gas quality.

To check the combustion quality, the CO_2 content or the O_2 content of the flue gas is measured. The actual values enable the prevailing air factor to be determined.

The relationship between the CO_2 or O_2 content and air factor λ is illustrated in the table below.

To achieve an optimum combustion control, the system regularly performs an automatic self-calibration; also after a power failure (shutdown). For this, the combustion is briefly regulated to max. ionization current (equals air factor $\lambda = 1$). The automatic calibration is performed shortly after the burner starts and lasts approximately 5 seconds.

During the calibration, higher than normal CO emissions may occur briefly.

Air factor λ - CO_2/O_2 content

| Air factor λ | O_2 content (%) | CO_2 content (%) for natural gas | CO_2 content (%) for liquid propane gas |
|----------------------|--------------------------|-------------------------------------------|--------------------------------------------------|
| 1.20 | 3.8 | 9.6 | 11.3 |
| 1.24 | 4.4 | 9.2 | 10.9 |
| 1.27 | 4.9 | 9.0 | 10.6 |
| 1.30 | 5.3 | 8.7 | 10.3 |
| 1.34 | 5.7 | 8.5 | 10.0 |
| 1.37 | 6.1 | 8.3 | 9.8 |
| 1.40 | 6.5 | 8.1 | 9.6 |
| 1.44 | 6.9 | 7.8 | 9.3 |
| 1.48 | 7.3 | 7.6 | 9.0 |

The Vitocrossal 300 CU3A boilers come equipped with Lambda Pro, the industry's first intelligent combustion management system.

Check Functioning of Safety Valves

Ensure proper operation of low water cut-off(s) (if applicable), pressure relief valve, and pump(s).

Check pressure gage, air vent and pressure relief valve. Ensure that pressure relief valve does not leak and that it operates in accordance with information provided by the manufacturer.



Refer to maintenance instructions supplied with low water cut-offs, pumps, etc.

Flush float water type low water cut-offs (if used).

Follow local regulations with respect to backflow preventers.

If oil-lubricated pumps are used, ensure proper lubrication.

If motorized zone valves are used, refer to maintenance instructions provided with zone valves.

Check Electrical Connections

Ensure all plug-in connectors and strain reliefs make positive contact and are seated properly.



Refer to the Installation Instructions

Check Gas Pipes and Fittings for Leaks

| | |
|--|-------------------------------------------------------------------------------------------------------------------------|
| | <p>! WARNING</p> <p>Hot surfaces can cause burns DO NOT TOUCH! Allow to cool before servicing</p> |
|--|-------------------------------------------------------------------------------------------------------------------------|

Note: For the tightness test, use only suitable and approved leak detecting agents and devices. Leak detecting agents with unsuitable contents (e.g. nitrites, sulphides) can lead to material damage. Remove residues of the leak detecting agent after testing.

| |
|------------------------------------------------------------------------------------------------------------------|
| <p>! WARNING</p> <p>Escaping gas leads to a risk of explosion. Check gas equipment for tightness.</p> |
|------------------------------------------------------------------------------------------------------------------|

| |
|------------------------------------------------------------------------------------------------------------------|
| <p>! WARNING</p> <p>The gas supply piping must be leak tested before placing the boiler in operation.</p> |
|------------------------------------------------------------------------------------------------------------------|

| |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>! CAUTION</p> <p>Ensure all joints of gas line are pressure tight and that gas valves do not leak when under normal operating pressure (use approved leak detection liquid).</p> |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Checking the Mixing Valve for Obstructions and Leaks

1. Remove the motorized lever from the mixing valve handle.
2. Check the mixing valve for ease of operation.
3. Check the mixing valve for leaks. Replace the O-rings if the mixing valve leaks.
4. Snap the motorized lever into place.

Example Layout 1

Matching the control unit to the heating system

Subject to the equipment level, the control unit must be matched to the system. Various system components are recognized automatically by the control unit and the relevant codes are adjusted automatically.

- For the selection of an appropriate scheme, see the following diagrams.
- For coding steps, see page 55.

System version 1

One heating circuit without mixing valve and DHW heating (optional solar DHW heating)

Applications

Heating system with DHW heating

Main components

- Gas condensing boiler models 26 to 199
- DHW tank (dual mode)
- Solar thermal system

Function description

The boiler circuit (30) and the DHW tank (10)/(14) are regulated by boiler heating circuit controller (1). The heating circuit and the DHW tank are supplied by their individual circulation pumps (31) and (13).

Heating mode

The boiler heating circuit controller regulates the boiler water temperature in weather-compensated or heat demand dependent mode (= supply temperature of the heating circuit without mixing valve).

DHW heating without a solar thermal system

If the temperature falls below the set DHW temperature selected at control unit (2), the burner of boiler (1) starts and circulation pump (13) of DHW tank (10) or (14) runs. Within the program set at control unit (2), DHW is heated with or without priority.

DHW heating by the solar thermal system

Solar circuit pump (23) starts and DHW tank (14) is heated up, if the temperature differential between collector temperature sensor (21) and tank temperature sensor (15) exceeds the start temperature differential.

Pump (23) is stopped according to the following criteria:

- The actual temperature drops below the stop temperature differential
- Exceeding the electronic temperature limit (up to 90°C) set in the solar control module (type SM1) (26)
- The temperature selected at high limit safety cut-out (16) (if installed) is reached

Demands for the auxiliary function are met by circulation pump (24).

Suppression of reheating of the DHW tank by the boiler in conjunction with solar control module (type SM1)

Reheating suppression takes place in two stages. Reheating DHW tank (14) by boiler (1) is suppressed as soon as DHW tank (14) is heated by collectors (20). For this, the set tank temperature for reheating is reduced by boiler (1). Suppression remains active for a certain time after solar circuit pump (23) has been switched off.

In the case of uninterrupted heating by collectors (20) (> 2 h) boiler (1) will only reheat, if the set tank temperature (coding address "67") selected at boiler circuit control unit (2) is not achieved.


In control unit (2), coding address "67" defaults a third set DHW temperature (setting range 10 to 95°C). This value must be below the first set DHW temperature.

DHW tank (14) will only be heated by boiler (1) when this set value is no longer achieved by the solar thermal system.

| Function/system components | Code | |
|----------------------------|--------|---------------------|
| | Adjust | Delivered condition |
| Operation with LPG | 82:1 | 82:0 |

Example Layout 1 *(continued)*

Hydraulic installation scheme ID: 4605300_1006_01




Note: This scheme is a basic example without shut-off valves or safety equipment.
This does not replace the need for local engineering.

Example Layout 1 *(continued)*

Equipment required ID: 4605300 1006 01

| Pos. | Designation |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ① | Boiler with Control unit Vitocrossal 300 with Vitotronic 200, type KW6B Outdoor temperature sensor ATS |
| ② | |
| ③ | |
| ⑩ | DHW heating by the boiler DHW tank Tank temperature sensor STS DHW recirculation pump ZP DHW pump UPSB |
| ⑪ | |
| ⑫ | |
| ⑬ | |
| ⑪ | DHW heating by the solar thermal system Tank temperature sensor STS DHW recirculation pump ZP DHW pump UPSB Dual mode DHW tank Tank temperature sensor SOL High limit safety cut-out STB |
| ⑫ | |
| ⑬ | |
| ⑭ | |
| ⑮ | |
| ⑯ | |
| ⑳ | Solar collectors Solar control module, type SM1 Collector temperature sensor KOL Solar-Divicon Solar circuit pump Circulation pump (transfer) Automatic thermostatic mixing valve |
| ㉑ | |
| ㉒ | |
| ㉓ | |
| ㉔ | |
| ㉕ | |
| ㉖ | |
| ㉓ | Heating circuit I Heating circuit pump, heating circuit A1 |
| ㉔ | |
| ⑤ | Accessories Internal extension H1: (integrated) ■ Connection, external safety solenoid valve (LPG) ■ Central fault message (alternative to extension EA1) Extension EA1 (integrated) External safety solenoid valve for LPG Central fault message External hook-up: ■ External blocking ■ External demand ■ External heating program changeover External set value 0 to 10 V Vitotrol 200A Vitotrol 300A KM BUS distributor, for several KM BUS participants KM BUS participant: ■ Extension EA1 ⑦ ■ Vitotrol 200A ⑥⑤ ■ Vitotrol 300A ⑥⑥ ■ Solar control module, type SM1 ㉖ Vitocom 100 LAN 1 |
| ⑦ | |
| ⑥⑤ | |
| ⑥② | |
| ⑥③ | |
| ⑥④ | |
| ⑥⑤ | |
| ⑥⑥ | |
| ⑥⑧ | |
| ⑥⑨ | |
| ⑦ | |
| ⑥⑤ | |
| ⑥⑥ | |
| ㉖ | |
| ⑦ | |
| ⑥⑤ | |
| ⑥⑥ | |
| ㉖ | |

Electrical installation diagram



Example Layout 2

System version 2

One heating circuit without mixing valve, one heating circuit with mixing valve and DHW heating (optional solar DHW heating)

Applications

Heating system with different heat sources and methods of DHW heating

- One heating circuit without mixing valve
- One heating circuit with 3-way mixing valve

Main components

- Gas condensing boiler models 26 to 199
- Heating circuit distribution
- DHW tank (dual mode)
- Solar thermal system

Function description

The heating circuits (30)/(40) and the DHW tank (10)/(14) are regulated by the boiler heating circuit controller (1). The heating circuits and DHW tank are each supplied by a separate circulation pump (31)/(43) and (13).

Heating mode

The boiler heating circuit controller regulates the boiler water temperature in weather-compensated mode (= supply temperature of the heating circuit without mixing valve) and the temperature level of the heating circuit with mixing valve via an extension kit for one heating circuit with mixing valve.

DHW heating without a solar thermal system

If the temperature falls below the set DHW temperature selected at control unit (2), the burner of boiler (1) starts and circulation pump (13) of DHW tank (10) or (14) runs. Within the time program selected at control unit (2), DHW is heated with or without priority.

In the case of absolute priority, heating circuit pump (43) of the heating circuit with mixing valve is switched off and mixing valve (44) is closed. With modulating priority, the heating circuit pump (43) of the heating circuit with mixing valve remains on, and mixing valve (44) is closed far enough for the set boiler water temperature for tank heating to be reached.

In this case, DHW tank (10) or (14) and heating circuit with mixing valve (40) are heated simultaneously.

DHW heating by the solar thermal system

Solar circuit pump (23) starts and DHW tank (14) is heated up, if the temperature differential between collector temperature sensor (21) and tank temperature sensor (15) exceeds the start temperature differential. Pump (23) is stopped according to the following criteria:

- The actual temperature drops below the stop temperature differential
- Exceeding the electronic temperature limit [up to 194°F (90°C)] set in the solar control module (type SM1) (26)
- The temperature selected at high limit safety cut-out (16) (if installed) is reached
- Demands for the auxiliary function are met by circulation pump (24).

Suppression of reheating of the DHW tank by the boiler in conjunction with solar control module (type SM1)

Reheating suppression takes place in two stages.


Reheating DHW tank (14) by boiler (1) is suppressed as soon as DHW tank (14) is heated by collectors (20). For this, the set tank temperature for reheating is reduced by boiler (1). Suppression remains active for a certain time after solar circuit pump (23) has been switched off.

In the case of uninterrupted heating by collectors (20) (> 2 h) boiler (1) will only reheat, if the set tank temperature (coding address "67") selected at boiler circuit control unit (2) is not achieved.

In control unit (2), coding address "67" defaults a third set DHW temperature [setting range 50°F to 203°F (10°C to 95°C)].

This value must be below the first set DHW temperature. DHW tank (14) will only be heated by boiler (1) when this set value is no longer achieved by the solar thermal system.

| Function/system components | Code | |
|----------------------------------------------------------------------------------------------|--------|---------------------|
| | Adjust | Delivered condition |
| Operation with LPG | 82:1 | 82:0 |
| System with only one heating circuit with mixing valve (without unregulated heating circuit) | 00:4 | 00:6 |
| | 00:3 | 00:5 |



Note: This scheme is a basic example without shut-off valves or safety equipment.
This does not replace the need for local engineering.

Example Layout 2 *(continued)*


Equipment required ID: 4605301_1006_02

| Pos. | Designation |
|------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ① | Boiler with Control unit Vitocrossal 300 with Vitotronic 200, type KW6B Outdoor temperature sensor ATS |
| ② | |
| ③ | |
| ⑩ | DHW heating by the boiler DHW tank Tank temperature sensor STS DHW recirculation pump ZP DHW pump UPSB |
| ⑪ | |
| ⑫ | |
| ⑬ | |
| ⑪ | DHW heating by the solar thermal system Tank temperature sensor STS DHW recirculation pump ZP DHW pump UPSB Dual mode DHW tank Tank temperature sensor SOL High limit safety cut-out STB |
| ⑫ | |
| ⑬ | |
| ⑭ | |
| ⑮ | |
| ⑯ | |
| ⑳ | Solar collectors Solar control module, type SM1 Collector temperature sensor KOL Solar-Divicon Solar circuit pump Circulation pump (transfer) Automatic thermostatic mixing valve |
| ㉑ | |
| ㉒ | |
| ㉓ | |
| ㉔ | |
| ㉕ | |
| ㉖ | |
| ③① | Heating circuit I Heating circuit pump, heating circuit A1 |
| ③② | |
| ④① | Heating circuit II Extension kit for one heating circuit with mixing valve M2 Components: ■ Supply temperature sensor M2 (contact temperature sensor) and ■ Mixing valve PCB with mixing valve motor or Extension kit for one heating circuit with mixing valve M2 Components: ■ Mixing valve PCB and supply temperature sensor M2 (contact temperature sensor) Mixing valve motor or Mixing valve motor M2 for flanged mixing valve and plug Temperature limiter for an underfloor heating circuit Heating circuit pump M2 and 3-way mixing valve |
| ④② | |
| ④③ | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

Example Layout 2 *(continued)*

Equipment required ID: 4605301_1006_02

| Pos. | Designation |
|------|--------------------------------------------------------|
| | Accessories |
| ⑤ | Internal extension H1: (integrated) |
| | ■ Connection, external safety solenoid valve (LPG) |
| | ■ Central fault message (alternative to extension EA1) |
| ⑦ | Extension EA1 (integrated) |
| ⑥0 | External safety solenoid valve for LPG |
| ⑥2 | Central fault message |
| ⑥3 | External hook-up: |
| | ■ External blocking |
| | ■ External demand |
| | ■ External heating program changeover |
| ⑥4 | External set value 0 to 10V |
| ⑥5 | Vitotrol 200A |
| ⑥6 | Vitotrol 300A |
| ⑥8 | KM BUS distributor, for several KM BUS participants |
| | KM BUS participant: |
| | ■ Extension EA1 ⑦ |
| | ■ Vitotrol 200A ⑥5 |
| | ■ Vitotrol 300A ⑥6 |
| | ■ Solar control module, type SM1 ②6 |
| ⑥9 | Vitocom 100 LAN 1 |

Example Layout 2 (continued)**Electrical installation diagram**

Example Layout 3

System version 3

One heating circuit without mixing valve and two heating circuits with mixing valve and DHW heating (optional solar DHW heating)

Applications

Heating system with different heat sources and methods of DHW heating

- One heating circuit without mixing valve
- Two heating circuits with 3-way mixing valve

Main components

- Gas condensing boiler models 26 to 199
- Heating circuit distribution
- DHW tank (dual mode)
- Solar thermal system

Function description

The heating circuits (30)/(40)/(50) and DHW tank (10)/(14) are regulated by boiler heating circuit controller (1). The heating circuits and DHW tank are each supplied by a separate circulation pump (31)/ (44)/(54) and (13).

Heating mode

The boiler heating circuit controller regulates the boiler water temperature in weather-compensated mode (= supply temperature of the heating circuit without mixing valve) and the temperature level of the heating circuit with mixing valve via an extension kit for one heating circuit with mixing valve.

DHW heating without a solar thermal system

If the temperature falls below the set DHW temperature selected at control unit (2), the burner of boiler (1) starts and circulation pump (13) of DHW tank (10) or (14) runs. Within the time program selected at control unit (2), DHW is heated with or without priority. In the case of absolute priority, heating circuit pumps (31)/(44)/(54) are switched off and mixing valves (45)/(55) are closed. With modulating priority control of the heating circuits with mixing valve, heating circuit pumps (44)/(54) remain on, and mixing valves (45)/(55) close far enough to enable the boiler water temperature set for tank heating to be reached. In this case, DHW tank (10) or (14) and heating circuit with mixing valve (40) and (50) are heated simultaneously.

DHW heating by the solar thermal system

Solar circuit pump (23) starts and DHW tank (14) is heated up, if the temperature differential between collector temperature sensor (21) and tank temperature sensor (15) exceeds the start temperature differential. Pump (23) is stopped according to the following criteria:

- The actual temperature drops below the stop temperature differential
- Exceeding the electronic temperature limit [up to 194°F (90°C)] set in the solar control module (type SM1) (26)
- The temperature selected at high limit safety cut-out (16) (if installed) is reached

Demands for the auxiliary function are met by circulation pump (24).


Suppression of reheating of the DHW tank by the boiler in conjunction with solar control module (type SM1)

Reheating suppression takes place in two stages. Reheating DHW tank (14) by boiler (1) is suppressed as soon as DHW tank (14) is heated by collectors (20). For this, the set tank temperature for reheating is reduced by boiler (1). Suppression remains active for a certain time after solar circuit pump (23) has been switched off. In the case of uninterrupted heating by collectors (23) (> 2 h) boiler (1) will only reheat, if the set tank temperature (coding address "67") selected at boiler circuit control unit (2) is not achieved. In control unit (2), coding address "67" defaults a third set DHW temperature [setting range 50°F to 203°F (10°C to 95°C)]. This value must be below the first set DHW temperature. DHW tank (14) will only be heated by boiler (1) when this set value is no longer achieved by the solar thermal system.

| Function/system components | Code | |
|----------------------------------------------------------------------------------------------|--------|---------------------|
| | Adjust | Delivered condition |
| Operation with LPG | 82:1 | 82:0 |
| System with only one heating circuit with mixing valve (without unregulated heating circuit) | 00:8 | 00:10 |
| | 00:7 | 00:9 |

Example Layout 3 (continued)

Hydraulic installation scheme ID: 4605302_1006_01



Note: This scheme is a basic example without shut-off valves or safety equipment.
This does not replace the need for local engineering.

Example Layout 3 *(continued)*


Equipment required ID: 4605302 1006 01

| Pos. | Designation |
|---------|----------------------------------------------------------------------------------|
| ① | Boiler with |
| ② | Control unit |
| | Vitocrossal 300 with |
| | Vitotronic 200, type KW6A |
| ③ | Outside temperature sensor ATS |
| | DHW heating by the boiler |
| ⑩ | DHW tank |
| ⑪ | Tank temperature sensor STS |
| ⑫ | DHW recirculation pump ZP |
| ⑬ | DHW pump UPSB |
| | DHW heating by the solar thermal system |
| ⑪ | Tank temperature sensor STS |
| ⑫ | DHW recirculation pump ZP |
| ⑬ | DHW pump UPSB |
| ⑭ | Dual mode DHW tank |
| ⑮ | Tank temperature sensor SOL |
| ⑯ | High limit safety cut-out STB |
| | Solar collectors |
| ⑳ | Solar control module, type SM1 |
| ㉔ | Collector temperature sensor KOL |
| ㉕ | Solar-Divicon |
| ㉖ | Solar circuit pump |
| ㉗ | Circulation pump (transfer) |
| ㉘ | Automatic thermostatic mixing valve |
| ③① | Heating circuit I |
| ③② | Heating circuit pump, heating circuit A1 |
| ④① / ⑤① | Heating circuit II and III |
| ④② / ⑤② | Extension kit for one heating circuit with mixing valve M2/M3 |
| | Components: |
| | ■ Supply temperature sensor M2/M3 (contact temperature sensor) |
| | and |
| ④⑤ / ⑤⑤ | ■ Mixing valve PCB with mixing valve motor |
| | or |
| ④① / ⑤① | Extension kit for one heating circuit with mixing valve M2/M3 |
| | Components: |
| ④② / ⑤② | ■ Mixing valve PCB and supply temperature sensor M2 (contact temperature sensor) |
| | Mixing valve motor |
| | or |
| ④⑤ / ⑤⑤ | Mixing valve motor M2 for flanged mixing valve and plug |
| ⑤③ | Temperature limiter for an underfloor heating circuit |
| ④④ / ⑤④ | Heating circuit pump M2 and 3-way mixing valve |

Example Layout 3 *(continued)*

Equipment required ID: 4605301_1006_02


| Pos. | Designation |
|------|--------------------------------------------------------|
| | Accessories |
| ⑤ | Internal extension H1: (integrated) |
| | ■ Connection, external safety solenoid valve (LPG) |
| | ■ Central fault message (alternative to extension EA1) |
| ⑦ | Extension EA1 (integrated) |
| ⑥0 | External safety solenoid valve for LPG |
| ⑥2 | Central fault message |
| ⑥3 | External hook-up: |
| | ■ External blocking |
| | ■ External demand |
| | ■ External heating program changeover |
| ⑥4 | External set value 0 to 10V |
| ⑥5 | Vitotrol 200A |
| ⑥6 | Vitotrol 300A |
| ⑥8 | KM BUS distributor, for several KM BUS participants |
| | KM BUS participant: |
| | ■ Extension EA1 ⑦ |
| | ■ Vitotrol 200A ⑥5 |
| | ■ Vitotrol 300A ⑥6 |
| | ■ Solar control module, type SM1 ②6 |
| ⑥9 | Vitocom 100, LAN1 |



Example Layout 4

Vitocrossal 300 CU3A with...

- DHW storage tank
- three zone circuits



Legend

- (A) Vitocrossal 300 CU3A boilers
- (B) DHW storage tank
- (C) DHW pump [output 21]
- (D) DHW recirculation pump [output 28/20]
- (E) Thermostat zone circuits 1, 2, 3 (dry contact)
- (F) Zone circuit 1 [output 157]
- (G) AM1 extension module (accessory)
- (H) Zone circuit 2 [output A1 - AM1 extension module]
- (I) Zone circuit 3 [output A2 - AM1 extension module]

Installation of different heating circuits...


- DHW production
- 3 zone circuits

Example Layout 4 (continued)

Equipment required

| Pos. | Designation |
|------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Ⓐ | Boiler with Control unit Vitocrossal 300 with Vitotronic 200, type KW6A Outside temperature sensor ATS |
| Ⓑ | DHW heating by the boiler DHW tank Tank temperature sensor STS DHW recirculation pump ZP DHW pump UPSB |
| Ⓓ | |
| Ⓒ | |
| Ⓔ | |
| Ⓕ | Zone circuit 1 [output 157] Heating circuit pump, heating circuit A1 |
| Ⓖ | Zone circuit 2 AM1 extension module function output A1 33:6 zone circuit pump 2 AM1 extension module function output A2 34:7 zone circuit pump 3 |
| Ⓗ | |
| Ⓖ | |
| Ⓖ | Zone circuit 3 Thermostat zone circuits 1, 2, 3 |

Start-up



Legend

- Ⓐ Fault indicator (red)
- Ⓑ ON indicator (green)
- Ⓒ Reset button
- Ⓓ ON/OFF switch

Starting the heating system


1. Check the heating system pressure at the pressure gauge. The heating system pressure is too low if the indicator is below 14 psi.
In this case, top up with water or notify your local heating contractor.
2. For room air dependent operation:
Check that the ventilation opening of the installation room are open and unrestricted.
Note: With room air dependent operation, the combustion air is drawn from the boiler room.
3. Open the gas shut-off valve.
Note: Ask your heating contractor to explain the positioning and handling of these components.
4. Switch ON the power supply, e.g. at a separate power switch or fuse.
5. Turn the ON/OFF switch “Ⓓ” ON. After a short time, the standard menu is displayed and the green ON indicator illuminates. Your heating system and, if installed, your remote controls are now ready for operation.



Refer to operating instructions for steps on shut down the system.

Menu Heating Circuits

There are two control levels available, the "Standard menu" and the "Extended menu".



Heating circuit interface

Legend

- Ⓐ Header (shows the heating program for displayed heating circuit Ⓓ)
- Ⓑ Current outside temperature
- Ⓒ Set room temperature
- Ⓓ Heating circuit which is selected for operation in the standard menu

Standard menu

Note: If your heating system has 2 or 3 heating circuits: You can select the heating circuit "HC1", "HC2" or "HC3" to be displayed in the standard menu.

If your heating system only has 1 heating circuit: No heating circuit name "HC..." is shown in the header.

In the standard menu, you can adjust and scan the most frequently used settings for the heating circuit shown in the header:

Press the following keys to set room temperature:

▲/▼ for the required value

OK to confirm

Heating programs:

⏻ Standby mode with frost protection monitoring

☞ Only DHW


☞ ☐ Heating and DHW

Press the following keys:

▶/◀ for the required heating program

OK to confirm

Note: 2 minutes after any setting has been made, the display automatically reverts to the standard menu.



Zone control interface


Menu Heating Circuits *(continued)*

Note: For any other connected heating circuits, use the settings in the extended menu.

Call up the standard menu as follows:

- If the screen saver is active
- Press any key except ?.

If you are somewhere in the menu:

Keep pressing  until the standard menu appears.

Symbols on the display

These symbols are not always displayed, but appear subject to the system version and the operating state.

Heating programs

 Standby mode with frost protection monitoring

 Only DHW


 Heating and DHW

Displays


HC1 (2, 3) To display the heating circuit selected in the standard menu

ZC1 (2, 3) To display the zone circuit selected in the standard menu

To change this, refer to the Operating Instructions

 Frost protection monitoring

 Central heating with standard temperature


 Central heating with reduced temperature

 Party mode enabled

 Economy mode enabled

In conjunction with a solar thermal system

 Solar circuit pump running

 Burner in operation

Messages

 Service message


 Fault message

Extended menu

In the extended menu, you can adjust and scan the settings from the control unit's range of functions used less frequently, (e.g. time programs and holiday programs).

Call up the extended menu

If the screen saver is active:


Press any key except ?, and then press .

If you are somewhere in the menu:

Press .

How to use the controls


The screen saver will become active if you have not adjusted any settings on the programming unit for a few minutes. The display brightness is reduced.



Legend

Ⓐ Dialogue line

Functional Description



Space heating mode

For operation with heating circuits the control unit calculates a boiler water setpoint temperature based on the outdoor or room temperature (where a room temperature dependent remote control is connected) and on the slope/shift of the heating curve.

The calculated boiler water setpoint temperature is transmitted to the burner control unit.

For operation with zone circuits, the boiler water setpoint operation temperature or calculated based on the slope/shift of the heating curve.

From the boiler water setpoint and the actual temperature the burner control calculates the degree of modulation required, and regulates the burner accordingly. The maximum operating boiler water temperature is limited in the burner control unit to 194°F (90°C) by the electronic temperature control.

The fixed high limits of the safety chain interlock the burner control unit at 210°F (99°C) boiler water temperature.

Domestic hot water supply with gas-fired space heating boiler

Domestic hot water heating is activated when the tank temperature is 4.5°F (2.5°C) below the tank temperature setpoint value. The burner and the tank DHW pump are switched on. In the factory default setting, the desired boiler water temperature is set at 36°F (20°C) above the tank temperature setpoint value. When the actual tank temperature rises 4.5°F (2.5°C) above the tank temperature setpoint value, the burner is switched off and the time delay function of the tank DHW pump is activated.

The temperature differential of 4.5°F (2.5°C) can be adjusted in coding level 2, address "59" DHW boost heating / additional heating function. This function will heat your DHW tank to a second DHW setpoint temperature within the fourth time phase. It can act as an "Anti-Legionnaire-Function" if the DHW supply is not heated to 140°F (60°C) during the regular time schedule.

You can activate this function by selecting a switching period for the fourth time phase. (See Operating Instructions.)

The temperature setpoint for this function is adjustable in coding address "58".

Adjusting the Heating Curves

The heating curves illustrate the relationship between the outdoor temperature and the boiler water or supply temperature.


To put it simply, the lower the outside temperature, the higher the boiler water or supply temperature.

The room temperature, again, depends on the boiler water or the supply temperature.

Note: If the heating system includes heating circuits with mixing valves, then the supply temperature of the heating circuit without mixing valve is higher by a selected differential (8 K in the delivered condition) than the supply temperature of the heating circuits with mixing valves. The differential temperature can be changed at coding address 9F.

Settings in the delivered condition:


- Slope = 1.4
- Shift = 0



Legend

- Ⓐ Heating curve slope for underfloor heating systems
- Ⓑ Heating curve slope for low temperature heating systems
- Ⓒ High temperature heating system, e.g. fintube radiation, fan coils

Changing the slope and shift



Legend

- Ⓐ Changing the slope
- Ⓑ Changing the shift (vertical parallel offset of the heating curve)


Extended menu:

- 1.
2. "Heating"
3. Select heating circuit.
4. "Heating curve"
5. "Slope" or "Shift"
6. Select heating curve according to the system requirements.

Adjusting the Heating Curves *(continued)*

Adjusting the set room temperature

Standard room temperature



Example 1: Adjustment of the standard room temperature from 68°F to 79°F (20°C to 26°C)

Legend


- Ⓐ Boiler water temperature or supply temperature
- Ⓑ Outdoor temperature
- Ⓒ Set room temperature
- Ⓓ Heating circuit pump "OFF"
- Ⓔ Heating circuit pump "ON"

Adjustment of the standard room temperature:



Refer to the Operating Instructions

Reduced room temperature



Example 2: Adjustment of reduced room temperature from 41°F to 57°F (5°C to 14°C)

Legend


- Ⓐ Boiler water temperature or supply temperature
- Ⓑ Outdoor temperature
- Ⓒ Set room temperature
- Ⓓ Heating circuit pump "OFF"
- Ⓔ Heating circuit pump "ON"

Adjustment of the reduced room temperature:



Refer to the Operating Instructions

Adjusting the Heating Curves *(continued)*



Legend


- Ⓐ Heating curve for operation with standard room temperature
- Ⓑ Heating curve for operation with reduced room temperature

Raising the reduced room temperature

During operation with reduced room temperature, the reduced set room temperature can be automatically raised subject to the outside temperature. The temperature is raised in accordance with the selected heating curve, but no higher than the set standard room temperature.

The outside temperature limits for the start and end of the temperature raising can be adjusted via coding addresses "F8" and "F9".

Example using the factory settings



Legend

- Ⓐ Start of operation with standard room temperature
- Ⓑ Set boiler water or supply temperature in accordance with the selected heating curve
- Ⓒ Set boiler water or supply temperature in accordance with coding address "FA": $122^{\circ}\text{F} + 20\% = 140^{\circ}\text{F}$
 $50^{\circ}\text{C} + 20\% = 60^{\circ}\text{C}$
- Ⓓ Duration of operation with raised set boiler water or supply temperature in accordance with coding address "Fb": 60 min

Reducing the heat-up time

During the transition from operation with reduced room temperature to operation with standard room temperature, the boiler water or supply temperature will be raised in accordance with the selected heating curve. The boiler water or supply temperature can be automatically increased.

The value and duration of the additional increase of the set boiler water or supply temperature can be adjusted in coding addresses "FA" and "FB".

Adjusting the Heating Curves *(continued)*

Allocating heating circuits to the remote control

The heating circuit allocation must be configured when commissioning the Vitotrol 200A or Vitotrol 300A.

| Heating circuit | Configuration | |
|------------------------------------------------------------------------|---------------|---------------|
| | Vitotrol 200A | Vitotrol 300A |
| The remote control affects the heating circuit without mixing valve A1 | HC 1 | HC 1 |
| The remote control affects the heating circuit with mixing valve M2 | HC 2 | HC 2 |
| The remote control affects the heating circuit with mixing valve M3 | HC 3 | HC 3 |

Note: One heating circuit can be allocated to the Vitotrol 200A. Up to three heating circuits can be allocated to the Vitotrol 300A. If the heating circuit allocation is later cancelled, reset coding address A0 for this heating circuit to 0 (fault message BC, BD, BE).

Connecting the Boiler to the LON System

Connecting the control unit to the LON

The LON communication module is pre-installed.





Note: The data transfer via LON can take several minutes.

Single boiler system with Vitotronic 200-H and Vitocom 100 LAN 1 (example)

Set the LON participant numbers and further functions via code 2 (see the following table).

Note: In the same LON system, the same number cannot be allocated twice. Only one Vitotronic may be programmed as fault manager.

Connecting the Boiler to a LON System *(continued)*


| Boiler control unit | Vitotronic 200-H (e.g. HK1B *1 mixing valve control) | Vitotronic 200-H (e.g. HK1B *1 multiple mixing valve control) | Vitocom *1 LON communication module |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
|  |  |  |  |
| Participant no. 1 Code "77:1" | Participant no. 10 Code "77:10" | Participant no. 11 Set code "77:11" | Participant no. 99 |
| Control unit is fault manager Code "79:1" | Control unit is not fault manager Code "79:0" | Control unit is not fault manager Code "79:0" | Device is fault manager |
| Control unit transmits the time Code "7B:1" | The control unit receives the time Set code "81:3" | The control unit receives the time Set code "81:3" | Device receives the time |
| Control unit transmits outside temperature Set code "97:2" | Control unit receives outside temperature Set code "97:1" | Control unit receives outside temperature Set code "97:1" | -- |
| LON participant fault monitoring Code "9C:20" | LON participant fault monitoring Code "9C:20" | LON participant fault monitoring Code "9C:20" | -- |

Carrying out a LON participant check

Communication with the system devices connected to the fault manager is tested with a participant check.

Preconditions:

- The control unit must be programmed as fault manager (code "79:1")
- The LON participant number must be programmed in all control units
- The LON participant list in the fault manager must be up to date

1. Press OK and  simultaneously for approx. 4 sec.
2. "Service functions"
3. "Participant check"
4. Select participant (e.g. participant 10).

The participant check for the selected participant is introduced.

- Successfully tested participants are designated with "OK".
- Unsuccessfully tested participants are designated with "Not OK".

Note: To carry out a new participant check, create a new participant list with menu item "Delete list?"

Note: If the participant check is carried out by another control unit, the participant number and "Wink" are shown on the display for approx. 1 min.

General

Accessing coding level 1

Note: Codes are displayed as plain text.

Codes that have no function due to the heating system equipment level or the setting of other codes are not displayed.

Heating systems with one heating circuit without mixing valve and one or two heating circuits with mixing valve:

The heating circuit without a mixing valve is designated "Heating circuit 1" and the heating circuits with mixing valve as "Heating circuit 2" or "Heating circuit 3".

If the heating circuits were given individual designations, the selected designation and "HC1", "HC2" or "HC3" appear instead:

1. Press **OK** and **≡** simultaneously for approximately 4 seconds.
2. "Coding level 1"
3. Select group of required coding address:
 - "General"
 - "Boiler"
 - "DHW"
 - "Heating circuit 1/2/3"
 - "All codes or solar"

In this group, all coding addresses from coding level 1 (except the coding addresses from the "Solar" group) are displayed in ascending order.

4. Select coding address.
5. Select value according to the following tables and confirm with **OK**.
6. If you want to reset all codes to their factory setting: Select "Standard setting" in "Coding level 1".
Note: This also resets codes from coding level 2.

| Coding in the factory setting | | Possible change | |
|-------------------------------|-----------------------------------------------------------------------------------------------------------------|---------------------|----------------------------------------------|
| System design | | | |
| 00:1 | System type 1: One heating circuit without mixing valve A1 (heating circuit 1), without DHW heating | 00:2 to 00:10 | For system type, see the following table: |

| Value address | System type | Description |
|---------------|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 00: ... | | |
| 1 | 1 | One heating circuit without mixing valve (heating circuit 1), without DHW heating. |
| 2 | 1 | One heating circuit without mixing valve (heating circuit 1), with DHW heating (code is adjusted automatically). |
| 3 | 2 | One heating circuit with mixing valve (heating circuit 2), without DHW heating. |
| 4 | 2 | One heating circuit with mixing valve (heating circuit 2) with DHW heating. |
| 5 | 2 | One heating circuit without mixing valve (heating circuit 1) and one heating circuit with mixing valve (heating circuit 2), without DHW heating (code is adjusted automatically). |
| 6 | 2 | One heating circuit without mixing valve (heating circuit 1) and one heating circuit with mixing valve (heating circuit 2), with DHW heating (code is adjusted automatically). |
| 7 | 3 | One heating circuit with mixing valve (heating circuit 2) and one heating circuit with mixing valve (heating circuit 3), without DHW heating. |
| 8 | 3 | One heating circuit with mixing valve (heating circuit 2) and one heating circuit with mixing valve (heating circuit 3), with DHW heating. |
| 9 | 3 | One heating circuit without mixing valve (heating circuit 1), one heating circuit with mixing valve (heating circuit 2) and one heating circuit with mixing valve (heating circuit 3), without DHW heating (code is adjusted automatically). |
| 10 | 3 | One heating circuit without mixing valve (heating circuit 1), one heating circuit with mixing valve (heating circuit 2) and one heating circuit with mixing valve (heating circuit 3), with DHW heating (code is adjusted automatically). |

General (continued)

| Coding in the factory set mode | | Possible change | |
|--------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Participant no. | | | |
| Internal circulation pump function | | | |
| 51:0 | System with low loss header: Internal circulation pump always starts when there is a heat demand | 51:1 | System with low loss header: When there is a heat demand, the internal circulation pump is only started if the burner is operating. Circulation pump is switched off after a 60 sec. delay. |
| | | 51:2 | System with heating water buffer DHW tank: When there is a heat demand, the internal circulation pump is only started if the burner is operating. Circulation pump is switched off after a 60 sec. delay. |
| 77:1 | LON participant number | 77:2 to 77:99 | LON participant number, adjustable from 1 to 99: 1 = Boiler 10 - 98 = Vitotronic 200-H 99 = Vitocom Note: Allocate each number only once. |
| Detached house/apartment building | | | |
| 7F:1 | Detached house | 7F:0 | Apartment building Separate adjustment of holiday program and time program for DHW heating possible. |
| Lock out controls | | | |
| 8F:0 | Operation in the standard menu and extended menu enabled. Note: The respective code is only activated when you exit the service menu. | 8F:1 | Operation in standard menu and extended menu blocked. Emissions test mode can be enabled. |
| | | 8F:2 | Operation enabled in the standard menu and blocked in the extended menu. Emissions test mode can be enabled. |
| Set supply temperature for external demand | | | |
| 9B:70 | Set supply temperature for external demand 158°F (70°C) | 9B:0 to 9B:127 | Set supply temperature for external demand adjustable from 32°F to 260°F (0°C to 127°C) (limited by boiler-specific parameters). |

Boiler

| Coding in the factory setting | | Possible change | |
|-------------------------------|------------------------------------------|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| Single/multi boiler system | | | |
| 21:0 | No service interval (hours run) selected | 21:1 to 21:100 | Number of hours run before the burner should be serviced is adjustable from 100 to 10,000 h One adjusting step $\bar{\Delta}$ 100 h. |
| Service interval in months | | | |
| 23:0 | No time interval for burner service | 23:1 to 23:24 | Interval adjustable from 1 to 24 months. |
| Service status | | | |
| 24:0 | No "Service" display | 24:1 | "Service" display (the address is automatically set and must be manually reset after a service has been carried out). |

DHW

| Coding in the factory setting | | Possible change | |
|-------------------------------|-------------------------------------------------------------------------------------------------------------------------|---------------------|---------------------------------------------------------------------------------------------------------|
| Enable DHW recirculation pump | | | |
| 67:40 | For solar DHW heating: Set DHW temperature 104°F (40°C). Reheating is suppressed above the selected set temperature. | 67:0 to 67:95 | Set DHW temperature adjustable from 32°F to 203°F (0°C to 95°C) (limited by boiler-specific parameters) |
| 73:0 | DHW recirculation pump: “ON” in accordance with the time program | 73:1 to 73:6 | “ON” from once per hour for 5 minutes up to 6 times per hour for 5 minutes during the time program. |
| | | 73:7 | Constantly “ON”. |

Solar

Note: The solar group is only displayed if a solar control module, type SM1, is connected.

| Coding in the factory setting | | Possible change | |
|----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|------------------------------------------------------------------------------------------------------------|
| Speed control solar circuit pump | | | |
| 02:0 | Solar circuit pump is not speed-controlled. | 02:1 | Solar circuit pump is speed-controlled with wave packet control. |
| | | 02:2 | Solar circuit pump is speed-controlled with PWM control. |
| DHW tank maximum temperature | | | |
| 08:60 | The solar circuit pump is switched off when the actual DHW tank temperature reaches 140°F (60°C) (maximum DHW tank temp). | 08:10 to 08:90 | Set DHW temperature adjustable from 50°F to 194°F (10°C to 90°C). |
| Stagnation time reduction | | | |
| 0A:5 | To protect the system components and heat transfer medium, the speed of the solar circuit pump is reduced when the differential between the actual DHW tank temperature and the set DHW tank temperature is less than 5 K. | 0A:0 | Stagnation time reduction disabled. |
| | | 0A:1 to 0A:40 | Temperature differential adjustable from 1 to 40 K. |
| Flow rate solar circuit | | | |
| 0F:70 | Solar circuit flow rate at the maximum pump speed 1.86 GPM (7 L/minute) | 0F:1 to 0F:255 | Flow rate adjustable from 0.02 to 6.7 GPM (0.1 to 25.5 L/minute;) 0.02 GPM (1 step Δ 0.1 L/minute.) |
| Extended solar control functions | | | |
| 20:0 | No extended control function enabled. | 20:1 | Additional function for DHW heating. |
| | | 20:2 | Differential temperature control 2. |
| | | 20:3 | Differential temperature control 2 and auxiliary function. |
| | | 20:4 | Differential temperature control 2 for central heating backup. |
| | | 20:5 | Thermostat function. |
| | | 20:6 | Thermostat function and auxiliary function. |
| | | 20:7 | Solar heating via external heat exchanger without additional temperature sensor. |
| | | 20:8 | Solar heating via external heat exchanger with additional temperature sensor. |
| | | 20:9 | Solar heating of two DHW tanks. |

Heating Circuit 1, 2 and 3

Select "Heating circuit ..."

| Coding in the factory setting | | Possible change | |
|-------------------------------|-----------------------------------------------------------------------|-----------------|-----------------------------------------------------------------------------------------------------|
| Priority DHW heating | | | |
| A2:2 | DHW tank priority applicable to heating circuit pump and mixing valve | A2:0 | Without DHW tank priority applied to heating circuit pump and mixing valve. |
| | | A2:1 | DHW tank priority only applicable to mixing valve. |
| | | A2:3 to A2:15 | Reduced priority applied to mixing valve (the heating circuit receives a reduced amount of energy). |

| | | | |
|---------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------|--------------------------------------------------------------------------------------------|
| Economy function outside temperature | | | |
| A5:5 | With heating circuit pump logic function (economy mode): Heating circuit pump "OFF" when the outside temperature (AT) is 1 K higher than the set room temperature (RTset) $AT > RTset + 1\text{ K}$ | A5:0 | Without heating circuit pump logic function. |
| | | A5:1 to A5:15 | With heating circuit pump logic function: Heating circuit pump "OFF"; see following table. |

| Parameter address A5:... | With heating circuit pump logic function: Heating circuit pump "OFF" |
|--------------------------|----------------------------------------------------------------------|
| 1 | $AT > RTset + 5\text{ K}$ |
| 2 | $AT > RTset + 4\text{ K}$ |
| 3 | $AT > RTset + 3\text{ K}$ |
| 4 | $AT > RTset + 2\text{ K}$ |
| 5 | $AT > RTset + 1\text{ K}$ |
| 6 | $AT > RTset$ |
| 7 | $AT > RTset - 1\text{ K}$ |
| to 15 | $AT > RTset - 9\text{ K}$ |

| Coding in the factory setting | | Possible change | |
|--------------------------------------------------------|------------------------------------|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Extended economy function adjusted outside temperature | | | |
| A6:36 | Extended economy function disabled | A6:5 to A6:35 | Extended economy function enabled, i.e. the burner and heating circuit pump will stop and the mixing valve close at a variable value, adjustable between 41°F and 95°F (5°C and 35°C) plus 1.8°F (1°C). The base value is the adjusted outside temperature. This value is based on the actual outside temperature and a time constant, which takes the cooling down of an average building into consideration. |

Heating Circuit 1, 2 and 3 *(continued)*

| Coding in the factory setting | | Possible change | |
|-----------------------------------------|------------------------------------------------------------------------------------------------|-------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Extended economy function mixing valve | | | |
| A7:0 | Without mixing valve economy function (only with circuits with mixing valve) | A7:1 | With mixing valve economy function (extended heating circuit pump logic): Heating circuit pump also “OFF”: - If the mixing valve has been closed for longer than 20 minutes. Heating circuit pump “ON”: - If the mixing valve changes to control function. - If there is a risk of frost. |
| Pump idle time, transition reduced mode | | | |
| A9:0 | Without pump idle time | A9:1 to A9:15 | With pump idle time: Heating circuit pump “OFF” if the set value is altered through a change in operating mode or through a change in the set room temperature With pump idle time, adjustable from 1 to 15. 1 = Short idle period 15 = Long idle period |
| Room temperature hook-up | | | |
| B0:0 | Only with heating circuit with mixing valve and remote control. Heating mode and reduced mode. | B0:1 | Heating mode: weather-compensated Reduced mode: with room temperature hook-up. |
| | | B0:2 | Heating mode: with room temperature hook-up Reduced mode. |
| | | B0:3 | Heating mode/reduced mode: with room temperature hook-up. |
| Economy function room temperature | | | |
| B5:0 | With remote control: No room temperature dependent heating circuit pump logic function | B5:1 to B5:8 | Heating circuit pump logic function, see the following table: |
| | | | |
| Parameter address | | With heating circuit pump logic function: | |
| B5:... | | Heating circuit pump “OFF” | Heating circuit pump “ON” |
| 1 | | RTactual > RTset + 5 K | RTactual < RTset + 4 K |
| 2 | | RTactual > RTset + 4 K | RTactual < RTset + 3 K |
| 3 | | RTactual > RTset + 3 K | RTactual < RTset + 2 K |
| 4 | | RTactual > RTset + 2 K | RTactual < RTset + 1 K |
| 5 | | RTactual > RTset + 1 K | RTactual < RTset |
| 6 | | RTactual > RTset | RTactual < RTset - 1 K |
| 7 | | RTactual > RTset - 1 K | RTactual < RTset - 2 K |
| 8 | | RTactual > RTset - 2 K | RTactual < RTset - 3 K |

Heating Circuit 1, 2 and 3 *(continued)*

| Coding in the factory setting | | Possible change | |
|----------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| Minimum supply temperature heating circuit | | | |
| C5:20 | Electronic minimum supply temp. limit 68°F (20°C) | C5:1 to C5:127 | Minimum limit adjustable from 34 to 260°F (1 to 127°C) (limited by boiler-specific parameters). |
| Maximum supply temperature heating circuit | | | |
| C6:74 | Electronic maximum supply temperature limit 165°F (74°C) | C6:10 to C6:127 | Maximum limit adjustable from 50 to 260°F (10 to 127°C) (limited by boiler-specific parameters). |
| Heating program - changeover | | | |
| D5:0 | The external heating program changeover changes the heating program to “Constant operation with reduced room temperature” or “Standby mode” | D5:1 | The external heating program changeover changes to “Constant operation with standard room temperature” (subject to coding address 3A, 3B and 3C). |
| Ext. heating program changeover to heating circuit | | | |
| D8:0 | No heating program changeover via extension EA1 | D8:1 | Heating program changeover via input DE1 at extension EA1. |
| | | D8:2 | Heating program changeover via input DE2 at extension EA1. |
| | | D8:3 | Heating program changeover via input DE3 at extension EA1. |
| Slab curing function (NOT USED) | | | |
| F1:0 | slab curing function disabled | F1:1 to F1:6 | -- |
| | | F1:15 | -- |
| Party mode time limit | | | |
| F2:8 | Time limit for party mode or external heating program changeover via push button: 8 h*1 | F2:0 | No time limit for party mode*1. |
| | | F2:1 to F2:12 | Time limit adjustable from 1 to 12 h*1. |

^{*1} Party mode ends automatically in the "Heating and DHW" program, when the system changes over to operation with standard room temperature.

Heating Circuit 1, 2 and 3 *(continued)*

| Coding in the factory setting | | Possible change | |
|------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| Start temperature raising | | | |
| F8:-5 | Temperature limit for terminating the reduced mode 23°F (-5°C); See operating instructions. Observe the setting of coding address "A3" | F8: + 10 to F8:-60 | Temperature limit adjustable from + 50°F to -76°F (+ 10°C to -60°C). |
| | | F8:-61 | Function disabled. |
| End temperature raising | | | |
| F9:-14 | Temperature limit for raising the reduced set room temperature 6.8°F (-14°C); See operating instructions. | F9: + 10 to F9:-60 | Temperature limit for raising the set room temperature to the value selected for standard mode adjustable from 50°F to -76°F (10°C to -60°C). |
| Set supply temperature heating circuit | | | |
| FA:20 | Raising the set boiler water temperature or the set supply temperature when changing from operation with reduced room temperature to operation with standard room temperature, by 20%. See operating instructions. | FA:0 to FA:50 | Temperature rise adjustable from 0% to 50%. |
| Duration set supply temperature increase | | | |
| FB:60 | Duration for raising the set boiler water temperature or the set supply temperature (see coding address "FA") 60 minutes. See operating instructions. | FB:0 to FB:150 | Duration adjustable from 0 to 300 minutes; 1 step $\bar{\Delta}$ 2 min. |

General

Calling up coding level 2



Note: At coding level 2, all codes are accessible, including the codes at coding level 1.

Codes that have not been assigned due to the heating system equipment level or the setting of other codes are not displayed.

Heating systems with one heating circuit without mixing valve and one or two heating circuits with mixing valve:

The heating circuit without mixing valve is designated "Heating circuit 1" and the heating circuits with mixing valve as "Heating circuit 2" or "Heating circuit 3".

If the heating circuits were given individual designations, the selected designation and "HC1", "HC2" or "HC3" appear instead:

1. Press **OK** and  simultaneously for approximately 4 seconds
2. Press **OK** and  simultaneously for approximately 4 seconds
3. "Coding level 2"
4. Select group of required coding address:
 - "General"
 - "Boiler"
 - "DHW"
 - "Heating circuit 1/2/3"
 - "All codes or solar"

In this group, all coding addresses (except the coding addresses from the "Solar" group) are displayed in ascending order.
5. Select coding address.
6. Select value according to the following tables and confirm with **"OK"**.
7. If you want to reset all codes to their factory setting: Select "Standard setting" in "Coding level 2".

Note: This also resets codes at coding level 1.

| Coding in the factory setting | | Possible change | |
|-------------------------------|--------------------------------------------------------------------------------------------------------|---------------------|-------------------------------------------|
| 00:1 | System type 1: One heating circuit without mixing valve A1 (heating circuit 1), without DHW heating | 00:2 to 00:10 | For system type, see the following table: |

| Value address | System type | Description |
|---------------|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 00: ... | | |
| 1 | 1 | One heating circuit without mixing valve (heating circuit 1), without DHW heating. |
| 2 | 1 | One heating circuit without mixing valve (heating circuit 1), with DHW heating, (code is adjusted automatically). |
| 3 | 2 | One heating circuit with mixing valve (heating circuit 2), without DHW heating. |
| 4 | 2 | One heating circuit with mixing valve (heating circuit 2) with DHW heating. |
| 5 | 2 | One heating circuit without mixing valve (heating circuit 1) and one heating circuit with mixing valve (heating circuit 2), without DHW heating (code is adjusted automatically). |
| 6 | 2 | One heating circuit without mixing valve (heating circuit 1) and one heating circuit with mixing valve (heating circuit 3), with DHW heating (code is adjusted automatically). |
| 7 | 3 | One heating circuit with mixing valve (heating circuit 2) and one heating circuit with mixing valve (heating circuit 3), without DHW heating. |
| 8 | 3 | One heating circuit with mixing valve (heating circuit 2) and one heating circuit with mixing valve (heating circuit 3), with DHW heating. |
| 9 | 3 | One heating circuit without mixing valve (heating circuit 1), one heating circuit with mixing valve (heating circuit 2) and one heating circuit with mixing valve (heating circuit 3), without DHW heating (code is adjusted automatically). |
| 10 | 3 | One heating circuit without mixing valve (heating circuit 1), one heating circuit with mixing valve (heating circuit 2) and one heating circuit with mixing valve (heating circuit 3), with DHW heating (code is adjusted automatically). |

General (continued)

| Coding in the factory setting | | Possible change | |
|-------------------------------|--------------------------------------------------------------------------------------------------------------------------|-----------------|----------------------------------------------------------------------------------------------------------------------------|
| 11:≠ 9 | No access to the coding addresses for the combustion controller parameters | 11:9 | Access open to the coding addresses for the combustion controller parameters. |
| 20:74 | Supply temperature for zone circuit 1, 164°F (74°C) | 20:20 to 20:85 | Supply temperature for zone circuits adjustable from 68°F to 185°F (20°C to 85°C) (limited by boiler specific parameters). |
| 27:74 | Supply temperature for zone circuit 2, 164°F (74°C) | 27:20 to 27:85 | Supply temperature for zone circuits adjustable from 68°F to 185°F (20°C to 85°C) (limited by boiler specific parameters). |
| 2A:0 | Without wireless outside temperature sensor | 2A:1 | With wireless outside temperature sensor (automatic recognition). |
| | | 2A:2 | Wireless outside temperature sensor not used. |
| 2C:74 | Supply temperature for zone circuit 3, 164°F (74°C) | 2C:20 to 2C:85 | Supply temperature for zone circuits adjustable from 68°F to 185°F (20°C to 85°C) (limited by boiler specific parameters). |
| 2D:0 | DO NOT ADJUST | -- | -- |
| 32:1 | DO NOT ADJUST | 32:0 | -- |
| 33:1 | Function output A1 at extension AM1: Heating circuit pump | 33:0 | Function output A1: DHW recirculation pump. |
| | | 33:2 | Function output A1: Circulation pump for DHW tank heating. |
| | | 33:3 | No function |
| | | 33:4 | No function |
| | | 33:5 | Zone circuit pump 1 |
| | | 33:6 | Zone circuit pump 2 |
| | | 33:7 | Zone circuit pump 3 |
| 34:0 | Function output A2 at extension AM1: DHW recirculation pump | 34:1 | Function output A2: Heating circuit pump. |
| | | 34:2 | Function output A2: Circulation pump for DHW tank heating. |
| | | 34:3 | No function |
| | | 34:4 | No function |
| | | 34:5 | Zone circuit pump 1 |
| | | 34:6 | Zone circuit pump 2 |
| | | 34:7 | Zone circuit pump 3 |
| 35:1 | With extension EA1 (automatic recognition). | 35:0 | Without extension EA1. |
| 36:0 | Function, output 157 at extension EA1: Fault message | 36:1 | Function output 157 : Feed pump. |
| | | 36:2 | Function output 157 : DHW recirculation pump. |
| | | 36:3-5 | No function |
| | | 36:6 | Zone circuit pump 1 |
| | | 36:7 | Zone circuit pump 2 |
| | | 36:8 | Zone circuit pump 3 |
| 39:2 | Function output 21 : Circulation pump for DHW tank heating | 39:0 | Function output 21 : DHW recirculation pump. |
| | | 39:1 | Function output 21 : Heating circuit pump. |

General (continued)

| Coding in the factory setting | | Possible change | |
|-------------------------------|------------------------------------------------------|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 3A:0 | Function input DE1 at extension EA1: Not assigned | 3A:1 | Function input DE1: Heating program - changeover. |
| | | 3A:2 | Function input DE1: External demand with set supply temperature. Supply temperature setting: Coding address 9B. Internal circulation pump function: Coding address 3F. |
| | | 3A:3 | Function input DE1: External blocking. Internal circulation pump function: Coding address 3E. |
| | | 3A:4 | Function input DE1: External blocking with fault message input Internal circulation pump function: Coding address 3E. |
| | | 3A:5 | Function input DE1: Fault message input. |
| | | 3A:6 | Function input DE1: Brief operation, DHW recirculation pump (push button function DHW recirculation pump runtime adjustment: Coding address 3D. |
| | | 3A:7 | Input zone circuit 1, constant |
| | | 3A:8 | Input zone circuit 1, weather compensated |
| 3B:0 | Function input DE2 at extension EA1: Not assigned | 3B:1 | Function input DE2: Heating program - changeover. |
| | | 3B:2 | Function input DE2: External demand with set supply temperature. Supply temperature setting: Coding address 9B. Internal circulation pump function: Coding address 3F. |
| | | 3B:3 | Function input DE2: External blocking. Internal circulation pump function: Coding address 3E. |
| | | 3B:4 | Function input DE2: External blocking with fault message input Internal circulation pump function: Coding address 3E. |
| | | 3B:5 | Function input DE2: Fault message input. |
| | | 3B:6 | Function input DE2: Brief operation, DHW recirculation pump (push button function). DHW recirculation pump runtime adjustment: Coding address 3D. |
| | | 3A:7 | Input zone circuit 1, constant |
| | | 3A:8 | Input zone circuit 1, weather compensated |

General (continued)

| Coding in the factory setting | | Possible change | |
|-------------------------------|------------------------------------------------------------------------------------------------|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 3C:0 | Function input DE3 at extension EA1: Not assigned | 3C:1 | Function input DE3: Heating program - changeover. |
| | | 3C:2 | Function input DE3: External demand with set supply temperature. Supply temperature setting: Coding address 9B. Internal circulation pump function: Coding address 3F. |
| | | 3C:3 | Function input DE3: External blocking. Internal circulation pump function: Coding address 3E. |
| | | 3C:4 | Function input DE3: External blocking with fault message input Internal circulation pump function: Coding address 3E. |
| | | 3C:5 | Function input DE3: Fault message input. |
| | | 3C:6 | Function input DE3: Brief operation, DHW recirculation pump (push button function). DHW recirculation pump runtime adjustment: Coding address 3D. |
| | | 3C:7 | Input zone circuit 3, constant |
| | | 3C:8 | Input zone circuit 3, weather compensated |
| 3D:5 | DHW recirculation pump runtime for brief operation: 5 minutes | 3D:1 to 3D:60 | DHW recirculation pump runtime adjustable from 1 to 60 minutes. |
| 3E:0 | Internal circulation pump stays in control mode at signal "External blocking" | 3E:1 | Internal circulation pump stops at signal "External blocking". |
| | | 3E:2 | Internal circulation pump starts at signal "External blocking". |
| 3F:0 | Internal circulation pump stays in control mode at signal "External demand" | 3F:1 | Internal circulation pump stops at signal "External demand". |
| | | 3F:2 | Internal circulation pump starts at signal "External demand". |
| 4B:0 | Function input [96]: Room thermostat (Vitolrol 100) for constant temperature control | 4B:1 | External demand. |
| | | 4B:2 | External blocking. |
| 51:0 | System with low loss header: Boiler circuit pump is always started when there is a heat demand | 51:1 | System with low loss header: When there is heat demand, the boiler circuit pump will only be started if the burner is running. Circulation pump is switched off when run-on time expires. |
| | | 51:2 | System with heating water buffer DHW tank: When there is a heat demand, the internal circulation pump will only be started when the burner is operational. |

General (continued)

| Coding in the factory setting | | Possible change | |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 52:0 | Without supply temperature sensor for low loss header | 52:1 | With supply temperature sensor for low loss header (automatic recognition). |
| 53:1 | Function connection 28 of the internal extension: DHW recirculation pump | 53:0 | Central fault message |
| | | 53:2 | External heating circuit pump (heating circuit 1). |
| | | 53:3 | External circulation pump for DHW tank heating. |
| | | 53:4 | No function |
| | | 53:5 | Zone circuit pump 1 |
| | | 53:6 | Zone circuit pump 2 |
| | | 53:7 | Zone circuit pump 3 |
| 54:0 | Without solar thermal system | 54:1 | With Vitosolic 100 (automatic recognition). |
| | | 54:2 | With Vitosolic 200 (automatic recognition). |
| | | 54:3 | With solar control module SM1 without auxiliary function (automatic recognition). |
| | | 54:4 | With solar control module SM1 with auxiliary function, e.g. central heating backup (automatic recognition). |
| 6E:50 | No correction of measured outside temperature | 6E:0 to 6E:100 | Outside correction in 0.1 K steps 0 to 49 = -5 K to -0.1 K 51 to 100 = 0.1 K to 5 K |
| 76:1 | With LON communication module (recognized automatically). | 76:0 | Without communication module |
| | | 76:2 | With cascade communication module (recognized automatically; only for constant temperature control units). |
| 77:1 | LON participant number | 77:2 to 77:99 | LON participant number, adjustable from 1 to 99: 1 = Boiler 10 - 98 = Vitotronic 200-H 99 = Vitocom Note: Allocate each number only once. |

General *(continued)*

| Coding in the factory setting | | Possible change | |
|-------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 79:1 | With LON communication module: Control unit is fault manager | 79:0 | Control unit is not fault manager. |
| 7B:1 | With LON communication module: Control unit transmits the time | 7B:0 | Does not transmit time. |
| 7F:1 | Detached house | 7F:0 | Apartment building Separate adjustment of holiday program and time program for DHW heating possible. |
| 80:6 | A fault message is displayed if a fault is active for at least 30 seconds | 80:0 | Immediate fault message. |
| | | 80:2 to 80:199 | Minimum fault duration until fault message occurs, adjustable from 10 sec to 995 sec; 1 step $\bar{\Delta}$ 5 sec. |
| 81:1 | Automatic summer/wintertime changeover | 81:0 | Manual summer/wintertime changeover. |
| | | 81:2 | Use of the radio clock receiver (automatic recognition). |
| | | 81:3 | With LON communication module: The control unit receives the time. |
| 82:0 | Operation with natural gas | 82:1 | Operation with LPG (only adjustable if coding address 11:9 has been set). |
| 88:0 | Temperature display in °C (Celsius) | 88:1 | Temperature display in °F (Fahrenheit). |
| 8A:175 | Do not adjust. | -- | -- |
| 8F:0 | Operation in the standard menu and extended menu enabled. Note: The respective code is only activated when you exit the service menu. | 8F:1 | Operation in standard menu and extended menu blocked. Emissions test mode can be enabled. |
| | | 8F:2 | Operation enabled in the standard menu and blocked in the extended menu. Emissions test mode can be enabled. |
| 90:36 | Time constant for calculating the adjusted outside temperature 6 h | 90:1 to 90:199 | Fast (low values) or slow (high values) matching of the supply temperature, subject to the set value when the outside temperature changes; 1 step $\bar{\Delta}$ 10 minutes. |

General *(continued)*

| Coding in the factory setting | | Possible change | |
|-------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|----------------------------------------------------------------------------------------------------------------------------------|
| 94:0 | Without Open Therm extension | 94:1 | With Open Therm extension (automatic recognition). |
| 95:0 | Without Vitocom 100 communication interface | 95:1 | With Vitocom 100 communication interface (automatic recognition). |
| 97:0 | With LON communication module: The outside temperature of the sensor connected to the control unit is utilized internally | 97:1 | Control unit receives outside temperature. |
| | | 97:2 | Control unit transmits the outside temperature to the Vitotronic 200-H. |
| 98:1 | With LON communication module: Viessmann system number (in conjunction with monitoring several systems via Vitocom 300) | 98:1 to 98:5 | System number adjustable from 1 to 5. |
| 99:0 | DO NOT ADJUST | -- | -- |
| 9A:0 | DO NOT ADJUST | -- | -- |
| 9B:70 | Set supply temperature for external demand 158°F (70°C) | 9B:0 to 9B:127 | Set supply temperature for external demand adjustable from 32°F to 260°F (0°C to 127°C) (limited by boiler-specific parameters). |
| 9C:20 | Monitoring LON participants. If a participant fails to respond, the values specified inside the control unit will be used after 20 minutes. Only then will a fault message be issued. | 9C:0 | No monitoring |
| | | 9C:5 to 9C:60 | Time adjustable from 5 to 60 minutes. |
| 9F:8 | Differential temperature 8 K; only in conjunction with mixing valve circuit | 9F:0 to 9F:40 | Differential temperature adjustable from 0 to 40 K. |

Boiler

| Coding in the factory setting | | Possible change | |
|-------------------------------|------------------------------------------------------------------------------------------|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| 06:95 | Maximum limit of the boiler water temperature, specified in °C by the boiler coding card | 06:20 to 06:127 | Maximum limit of the boiler water temperature within the ranges specified by the boiler. |
| 0D:0 | DO NOT ADJUST | -- | -- |
| 0E:0 | DO NOT ADJUST | -- | -- |
| 13:1 | DO NOT ADJUST | -- | -- |
| 14:1 | DO NOT ADJUST | -- | -- |
| 15:1 | DO NOT ADJUST | -- | -- |
| 21:0 | No service interval (hours run) selected | 21:1 to 21:100 | Number of hours run before the burner should be serviced is adjustable from 100 to 10,000 h One adjusting step $\bar{\Delta}$ 100 h. |
| 23:0 | No time interval for burner service | 23:1 to 23:24 | Interval adjustable from 1 to 24 months. |
| 24:0 | No "Service" display | 24:1 | "Service" display (the address is automatically set and must be manually reset after a service has been carried out). |
| 2E:0 | DO NOT ADJUST | -- | -- |
| 38:0 | Status burner control unit: Operational (no fault) | 38: \neq 0 | Status burner control unit: Fault. |

DHW

| Coding in the factory setting | | Possible change | |
|-------------------------------|------------------------------------------------------------------------------------------------------|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 56:0 | Set DHW temperature adjustable from 50 to 140°F (10 to 60°C) | 56:1 | Set DHW temperature adjustable from 50°F to over 140°F (10°C to over 60°C). Note: Maximum value subject to boiler coding card. Observe the maximum permissible DHW temperature [max. 154°F (68°C)]. |
| 57:0 | DO NOT ADJUST | -- | -- |
| 58:0 | Without auxiliary function for DHW heating | 58:10 to 58:60 | Input of a second set DHW temperature, adjustable from 50°F to 140°F (10°C to 60°C) (observe coding addresses "56" and "63"). |
| 59:0 | DHW tank heating: Starting point -2.5 K Stopping point +2.5 K | 59:1 to 59:10 | Starting point adjustable from 1 to 10 K below the set value. |
| 5B:0 | DHW tank directly connected to the boiler | 5b:1 | DHW tank connected downstream of the low loss header. |
| 5E:0 | Circulation pump for DHW tank heating stays in control mode at signal "External blocking" | 5E:1 | Circulation pump for DHW tank heating stops at signal "External blocking". |
| | | 5E:2 | Circulation pump for DHW tank heating starts at signal "External blocking". |
| 5F:0 | Circulation pump for DHW tank heating stays in control mode at signal "External demand" | 5F:1 | Circulation pump for DHW tank heating stops at signal "External demand". |
| | | 5F:2 | Circulation pump for DHW tank heating starts at signal "External demand". |
| 60:20 | During DHW heating, the boiler water temperature is maximum 20 K higher than the set DHW temperature | 60:5 to 60:25 | The differential between the boiler water temperature and the set DHW temperature is adjustable from 5 to 25 K. |
| 62:2 | Circulation pump with 2 minutes run-on time after DHW tank heating | 62:0 | Circulation pump without run-on. |
| | | 62:1 to 62:15 | Run-on time adjustable from 1 to 15 minutes. |

DHW *(continued)*

| Coding in the factory setting | | Possible change | |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------|----------------------|-------------------------------------------------------------------------------------------------------------------|
| 65:0 | DO NOT ADJUST | 65:0 to 65:3 | -- |
| 67:40 | For solar DHW heating: Set DHW temperature 104°F (40°C). Reheating is suppressed above the selected set temperature. | 67:0 to 67:95 | Set DHW temperature adjustable from 32°F to 203°F (0°C to 95°C) (limited by boiler- specific parameters) |
| 6F:100 | Maximum output for DHW heating in %, specified by the boiler coding card | 6F:0 to 6F:100 | Maximum output for DHW heating adjustable from minimum output to 100%. |
| 71:0 | DHW recirculation pump: "ON" in accordance with the time program | 71:1 | "OFF" during DHW heating to first set value. |
| | | 71:2 | "ON" during DHW heating to first set value. |
| 72:0 | DHW recirculation pump: "ON" in accordance with the time program | 72:1 | "OFF" during DHW heating to second set value. |
| | | 72:2 | "ON" during DHW heating to second set value. |
| 73:0 | DHW recirculation pump: "ON" in accordance with the time program | 73:1 to 73:6 | "ON" from once per hour for 5 minutes up to 6 times per hour for 5 minutes during the time program. |
| | | 73:7 | Constantly "ON". |

Solar

Note: The solar group is only displayed if a solar control module, type SM1, is connected.

| Coding in the factory setting | | Possible change | |
|-------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 00:8 | The solar circuit pump starts when the collector temperature exceeds the actual DHW tank temperature by 8 K. | 00:2 to 00:30 | The differential between the actual DHW tank temperature and the start point for the solar circuit pump can be adjusted from 2 to 30 K. |
| 01:4 | The solar circuit pump is switched off when the differential between the collector temperature and the actual DHW tank temperature is less than 4 K. | 01:1 to 01:29 | The differential between the actual DHW tank temperature and the stop point for the solar circuit pump can be adjusted from 1 to 29 K. |
| 02:0 | Solar circuit pump (stepped) is not speed-controlled | 02:1 | Solar circuit pump is speed-controlled with wave packet control. |
| | | 02:2 | Solar circuit pump is speed-controlled with PWM control. |
| 03:10 | The temperature differential between the collector temperature and actual DHW tank temperature is regulated to 10 K. | 03:5 to 03:20 | The differential temperature control between collector temperature and actual DHW tank temperature can be adjusted from 5 to 20 K. |
| 04:4 | Controller amplification of the speed control 4%/K. | 04:1 to 04:10 | Controller amplification adjustable from 1 to 10%/K. |
| 05:10 | Minimum speed of the solar circuit pump 10% of the maximum speed. | 05:2 to 05:100 | Minimum speed of the solar circuit pump is adjustable from 2% to 100%. |
| 06:75 | Maximum speed of the solar circuit pump 75% of the maximum possible speed. | 06:1 to 06:100 | Maximum speed of the solar circuit pump is adjustable from 1% to 100%. |
| 07:0 | Interval function of the solar circuit pump switched off. | 07:1 | Interval function of the solar circuit pump switched on. To capture the collector temperature more accurately, the solar circuit pump starts for short cycles. |
| 08:60 | The solar circuit pump is switched off when the actual DHW tank temperature reaches 140°F (60°C) (maximum DHW tank temperature). | 08:10 to 08:90 | The maximum DHW tank temperature can be adjusted from 50°F to 194°F (10°C to 90°C). |

Solar *(continued)*

| Coding in the factory setting | | Possible change | |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| 09:130 | The solar circuit pump stops if the collector temperature reaches 266°F (130°C) (maximum collector temperature to protect the system components) | 09:20 to 09:200 | Temperature adjustable from 68°F to 392°F (20°C to 200°C). |
| 0A:5 | Temperature differential for stagnation time reduction (reduction in the speed of the solar circuit pump to protect system components and heat transfer medium) 5 K. | 0A:0 to 0A:40 | The differential between the set DHW tank temperature and the start point for reducing the stagnation time can be adjusted from 0 to 40 K. |
| 0B:0 | Collector frost protection function switched off | 0B:1 | Collector frost protection function switched on (not required with Viessmann heat transfer medium). |
| 0C:1 | Δt monitoring switched on. No flow rate captured in the solar circuit, or flow rate too low. | 0C:0 | Δt monitoring switched off. |
| 0D:1 | Night circulation monitoring switched on. Unintentional flow rate is captured in the solar circuit (e.g. at night). | 0D:0 | Night circulation monitoring switched off. |
| 0E:1 | Calculation of solar yield with Viessmann heat transfer medium | 0E:2 | Calculation of solar yield with water as heat transfer medium (do not select as operation is only possible with Viessmann heat transfer medium). |
| | | 0E:0 | Calculation of solar yield switched off. |
| 0F:70 | The flow rate in the collector circuit at the maximum pump speed is set to 1.8 USG (7 L/minute). | 0F:1 to 0F:255 | Flow rate in the collector circuit adjustable from 1.6 to 6.7 USG/minute (0.1 to 25.5 L/minute). |
| 10:0 | Target temperature control switched off (see coding address "11"). | 10:1 | Target temperature control switched on. |

Solar *(continued)*

| Coding in the factory setting | | Possible change | |
|-------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|-------------------------------------------------------------------------------------------|
| 11:50 | Set DHW tank temperature for solar 122°F (50°C). - Target temperature control switched on (code 10:1): Temperature at which the solar heated water in the DHW tank is to be stratified. - Extended control functions set to heat two DHW tanks (code 20:8): If the actual temperature of a DHW tank reaches the selected set DHW tank temperature, heating is switched to the second DHW tank. | 11:10 to 11:90 | The set DHW tank temperature for solar can be adjusted from 50°F to 194°F (10°C to 90°C). |
| 12:10 | Minimum collector temperature 68°F (20°C). The solar circuit pump is only started when the set minimum collector temperature is exceeded at the collector temperature sensor. | 12:0 | Minimum collector temperature function switched off. |
| | | 12:1 to 12:90 | Minimum collector temperature adjustable from 34°F to 194°F (1°C to 90°C). |
| 20:0 | No extended control functions enabled. | 20:1 | Auxiliary function for DHW heating. |
| | | 20:2 | Differential temperature control 2. |
| | | 20:3 | Differential temperature control 2 and auxiliary function. |
| | | 20:4 | Differential temperature control 2 for central heating backup. |
| | | 20:5 | Thermostat function. |
| | | 20:6 | Thermostat function and auxiliary function. |
| | | 20:7 | Solar heating via external heat exchanger without additional temperature sensor. |
| | | 20:8 | Solar heating via external heat exchanger with additional temperature sensor. |
| | | 20:9 | Solar heating of two DHW tanks. |
| 22:8 | Start temperature differential for central heating backup: 8 K. (code 20:4 must be selected) | 22:2 to 22:30 | Start temperature differential for central heating backup is adjustable from 21 to 30 K. |

Solar *(continued)*

| Coding in the factory setting | | Possible change | |
|-------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|----------------------------------------------------------------------------------------|
| 23:4 | Stop temperature differential for central heating backup: 4 K. (code 20:4 must be selected) | 23:2 to 23:30 | Stop temperature differential for central heating backup is adjustable from 1 to 29 K. |
| 24:40 | Start temperature for thermostat function 104°F (40°C). (code 20:5 or 20:6 must be selected) | 24:0 to 24:100 | Start temperature for thermostat function adjustable from 0 to 100 K. |
| 25:50 | Stop temperature for thermostat function 122°F (50°C). (code 20:5 or 20:6 must be selected) | 25:0 to 25:100 | Start temperature for thermostat function is adjustable from 0 to 100 K. |
| 26:1 | Priority for DHW tank 1 with alternate heating. Only when setting code 20:9. | 26:0 | Priority for DHW tank 1 without alternate heating. |
| | | 26:2 | Priority for DHW tank 2 without alternate heating. |
| | | 26:3 | Priority for DHW tank 2 with alternate heating. |
| | | 26:4 | Alternate heating without priority for one of the DHW tank. |
| 27:15 | Alternate heating time 15 minutes. The DHW tank without priority is heated at most for the duration of the set alternate heating time if the DHW tank with priority is heated up. | 27:5 to 27:60 | The alternate heating time is adjustable from 5 to 60 minutes. |
| 28:3 | Alternate pause time 3 minutes After the selected alternate heating time for the DHW tank without priority has expired, the rise in collector temperature is captured during the alternate pause time. | 28:1 to 28:60 | The alternate pause time is adjustable from 1 to 60 minutes. |

Heating Circuit 1, 2 and 3

| Coding in the factory setting | | Possible change | |
|-------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|-----------------|-----------------------------------------------------------------------------------------------------|
| A0:0 | Without remote control | A0:1 | With Vitotrol 200A (automatic recognition). |
| | | A0:2 | With Vitotrol 300A (automatic recognition). |
| A1:0 | All possible settings at the remote control can be accessed | A1:1 | Only party mode can be set at the remote control (only for Vitotrol 200A). |
| A2:2 | DHW tank priority applicable to heating circuit pump and mixing valve | A2:0 | Without DHW tank priority applied to heating circuit pump and mixing valve. |
| | | A2:1 | DHW tank priority only applicable to mixing valve. |
| | | A2:3 to A2:15 | Reduced priority applied to mixing valve (the heating circuit receives a reduced amount of energy). |
| A3:2 | Outside temperature below 34°F (1°C): Heating circuit pump "ON" Outside temperature above 37°F (3°C): Heating circuit pump "OFF" | A3:-9 to A3:15 | Heating circuit pump "ON/OFF" (see following table). |

Note: When selecting a value below 33.8°F (1°C), there is a risk of pipes outside the thermal envelope of the building freezing up. The standby mode in particular should be taken into consideration, e.g. during holidays.

| Parameter address A3:... | Heating circuit pump | |
|--------------------------|-------------------------------|-------------------------------|
| | "ON" | "OFF" |
| -9 | 14°F (-10°C) | 17.6°F (-8°C) |
| -8 | 15.8°F (-9°C) | 19.4°F (-7°C) |
| -7 | 17.6°F (-8°C) | 21.2°F (-6°C) |
| -6 | 19.4°F (-7°C) | 23°F (-5°C) |
| -5 | 21.2°F (-6°C) | 24.8°F (-4°C) |
| -4 | 23°F (-5°C) | 26.6°F (-3°C) |
| -3 | 24.8°F (-4°C) | 28.4°F (-2°C) |
| -2 | 26.6°F (-3°C) | 32.2°F (-1°C) |
| -1 | 28.4°F (-2°C) | 32°F (0°C) |
| 0 | 32.2°F (-1°C) | 33.8°F (1°C) |
| 1 | 32°F (0°C) | 35.6°F (2°C) |
| 2 to 15 | 33.8 to 57.2°F to (1 to 14°C) | 37.4 to 60.8°F to (3 to 16°C) |

Heating Circuit 1, 2 and 3 *(continued)*

| Coding in the factory setting | | Possible change | |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| A4:0 | With frost protection | A4:1 | No frost protection; this setting is only possible if code "A3:-9" has been selected. Note: "Important" observe for code "A3". |
| A5:5 | With heating circuit pump logic function (economy mode): Heating circuit pump "OFF" when the outside temperature (AT) is 1 K higher than the set room temperature (RTset) $AT > RTset + 1 K$ | A5:0 | Without heating circuit pump logic function. |
| | | A5:1 to A5:15 | With heating circuit pump logic function: Heating circuit pump "OFF"; see following table. |

| Parameter address A5:... | With heating circuit pump logic function: Heating circuit pump "OFF" |
|--------------------------|----------------------------------------------------------------------|
| 1 | $AT > RTset + 5 K$ |
| 2 | $AT > RTset + 4 K$ |
| 3 | $AT > RTset + 3 K$ |
| 4 | $AT > RTset + 2 K$ |
| 5 | $AT > RTset + 1 K$ |
| 6 | $AT > RTset$ |
| 7 to 15 | $AT > RTset - 1 K$ to $AT > RTset - 9 K$ |

| Coding in the factory setting | | Possible change | |
|-------------------------------|---------------------------------------|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A6:36 | Extended economy function disabled | A6:5 to A6:35 | Extended economy function enabled, i.e. the burner and heating circuit pump will stop and the mixing valve close at a variable value, adjustable between 41 °F and 95 °F (5 °C and 35 °C) plus 1.8 °F (1 °C). The base value is the adjusted outside temperature. This value is based on the actual outside temperature and a time constant, which takes the cooling down of an average building into consideration. |
| A7:0 | Without mixing valve economy function | A7:1 | With mixing valve economy function (extended heating circuit pump logic): Heating circuit pump also "OFF": - If the mixing valve has been attempting to close for longer than 20 minutes. Heating circuit pump "ON": - If the mixing valve changes to control function. - If there is a risk of frost. |

Heating Circuit 1, 2 and 3 *(continued)*

| Coding in the factory setting | | Possible change | |
|-------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|------------------------------------------------------------------------------------|
| A9:0 | With pump idle time: Heating circuit pump "OFF" if the set value is altered through a change in operating mode or through a change in the set room temperature | A9:0 | Without pump idle time. |
| | | A9:1 to A9:15 | With pump idle time, adjustable from 1 to 15. |
| B0:0 | With remote control: Heating mode/reduced mode: (only change the code for the heating circuit with mixing valve) | B0:1 | Heating mode: weather compensated. Reduced mode: with room temperature hook-up. |
| | | B0:2 | Heating mode: with room temperature hook-up. Reduced mode: weather-compensated. |
| | | B0:3 | Heating mode/reduced mode: with room temperature hook-up. |
| B2:8 | With remote control unit and for the heating circuit, operation with room temperature hook-up must be programmed: Room influence factor 8 (change the code only for the heating circuit with mixing valve) | B2:0 | Without room influence. |
| | | B2:1 to B2:64 | Room influence factor adjustable from 1 to 64. |
| B5:0 | With remote control: No room temperature-dependent heating circuit pump logic function (only change the code for the heating circuit with mixing valve) | B5:1 to B5:8 | Heating circuit pump logic function, see the following table: |

| Parameter address B5:... | With heating circuit pump logic function: | |
|--------------------------|-------------------------------------------|---------------------------------------|
| | Heating circuit pump "OFF" | Heating circuit pump "ON" |
| 1 | $RT_{actual} > RT_{set} + 5\text{ K}$ | $RT_{actual} < RT_{set} + 4\text{ K}$ |
| 2 | $RT_{actual} > RT_{set} + 4\text{ K}$ | $RT_{actual} < RT_{set} + 3\text{ K}$ |
| 3 | $RT_{actual} > RT_{set} + 3\text{ K}$ | $RT_{actual} < RT_{set} + 2\text{ K}$ |
| 4 | $RT_{actual} > RT_{set} + 2\text{ K}$ | $RT_{actual} < RT_{set} + 1\text{ K}$ |
| 5 | $RT_{actual} > RT_{set} + 1\text{ K}$ | $RT_{actual} < RT_{set}$ |
| 6 | $RT_{actual} > RT_{set}$ | $RT_{actual} < RT_{set} - 1\text{ K}$ |
| 7 | $RT_{actual} > RT_{set} - 1\text{ K}$ | $RT_{actual} < RT_{set} - 2\text{ K}$ |
| 8 | $RT_{actual} > RT_{set} - 2\text{ K}$ | $RT_{actual} < RT_{set} - 3\text{ K}$ |

Heating Circuit 1, 2 and 3 *(continued)*

| Coding in the factory setting | | Possible change | |
|-------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| C5:20 | Electronic minimum supply temperature limit 68°F (20°C) | C5:1 to C5:127 | Minimum limit adjustable from 1 °F to 260°F (-17°C to 127°C) (limited by boiler-specific parameters). |
| C6:74 | Electronic maximum supply temperature limit 165°F (74°C) | C6:10 to C6:127 | Maximum limit adjustable from 50°F to 260°F (10°C to 127°C) (limited by boiler-specific parameters). |
| D3:14 | Heating curve slope = 1.4 | D3:2 to D3:35 | Heating curve slope adjustable from 0.2 to 3.5 (see page 50). |
| D4:0 | Heating curve shift = 0 | D4:-13 to D4:40 | Heating curve shift adjustable from -13 to 40 (see page 50). |
| D5:0 | The external heating program changeover changes the heating program to "Constant operation with reduced room temperature" or "Standby mode" | D5:1 | The external heating program changeover changes to "Constant operation with standard room temperature" (subject to coding address 3A, 3B and 3C). |
| D6:0 | Heating circuit pump stays in control mode at signal "External blocking" | D6:1 | Heating circuit pump stops at signal "External blocking" (subject to coding addresses 3A, 3B and 3C). |
| | | D6:2 | Heating circuit pump starts at signal "External blocking" (subject to coding addresses 3A, 3B and 3C). |
| D7:0 | Heating circuit pump stays in control mode at signal "External demand" | D7:1 | Heating circuit pump stops at signal "External demand" (subject to coding addresses 3A, 3B and 3C). |
| | | D7:2 | Heating circuit pump starts at signal "External demand" (subject to coding addresses 3A, 3B and 3C). |
| D8:0 | No heating program changeover via extension EA1 | D8:1 | Heating program changeover via input DE1 at extension EA1. |
| | | D8:2 | Heating program changeover via input DE2 at extension EA1. |
| | | D8:3 | Heating program changeover via input DE3 at extension EA1. |
| E1:1 | DO NOT ADJUST | -- | -- |
| E2:50 | With remote control: No display correction for the actual room temperature | E2:0 to E2:49 | Display correction -5 K to Display correction -0.1 K. |
| | | E2:51 to E2:99 | Display correction +0.1 K to Display correction +4.9 K. |

Heating Circuit 1, 2 and 3 *(continued)*


| Coding in the factory setting | | Possible change | |
|-------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| E5:0 | Without external variable speed heating circuit pump | E5:1 | With external variable speed heating circuit pump. |
| E6:... | Maximum speed of the variable speed heating circuit pump in % of the maximum speed in standard mode. Value is specified by boiler-specific parameters | E6:0 to E6:100 | Maximum speed adjustable from 0 to 100%. |
| E7:30 | Minimum speed of the variable speed heating circuit pump: 30% of the maximum speed | E7:0 to E7:100 | Minimum speed adjustable from 0% to 100% of the maximum speed. |
| E8:1 | Minimum speed in operation with reduced room temperature subject to the setting in coding address "E9" | E8:0 | Speed subject to the setting in coding address "E7". |
| E9:45 | Speed of the variable speed heating circuit pump: 45% of the maximum speed during operation with reduced room temperature | E9:0 to E9:100 | Speed adjustable from 0 to 100% of the maximum speed during operation with reduced room temperature. |
| F1:0 | Slab curing function disabled | -- | -- |
| F2:8 | Time limit for party mode or external heating program changeover via push button: 8 h ^{*1} | F2:0 | No time limit for party mode ^{*1} . |
| | | F2:1 to F2:12 | Time limit adjustable from 1 to 12 h ^{*1} . |
| F5:12 | Run-on time of the boiler circuit pump in heating mode: 12 minutes. | F5:0 | No run-on time for the circulation pump in the heating circuit connection set. |
| | | F5:1 to F5:20 | Run-on time of the circulation pump in the heating circuit connection set adjustable from 1 to 20 minutes. |
| F8:-5 | Temperature limit for terminating the reduced mode 23°F (-5°C); See operating instructions. Observe the setting of coding address "A3". | F8: + 10 to F8:-60 | Temperature limit adjustable from 50 to -76°F (10 to -60°C). |
| | | F8:-61 | Function disabled. |
| F9:-14 | Temperature limit for raising the reduced set room temperature 6.8°F (-14°C); See operating instructions. | F9: + 10 to F9:-60 | Temperature limit for raising the set room temperature to the value selected for standard mode adjustable from 50°F to -76°F (10°C to -60°C). |
| FA:20 | Raising the set boiler water temperature or the set supply temperature when changing from operation with reduced room temperature to operation with standard room temperature, by 20%. See operating instructions. | FA:0 to FA:50 | Temperature rise adjustable from 0% to 50%. |
| FB:60 | Duration for raising the set boiler water temperature or the set supply temperature (see coding address "FA") 60 minutes See operating instructions. | FB:0 to FB:150 | Duration adjustable from 0 to 300 minutes; 1 step $\bar{\Delta}$ 2 minutes. |

^{*1} Party mode ends automatically in the "Heating and DHW" program, when the system changes over to operation with standard room temperature.


Zone Circuit 1, 2 and 3

| Coding in the factory setting | | Possible change | |
|-------------------------------|---------------------------|-----------------------|-------------------------------------------------------------------|
| 1B:14 | Heating curve slope = 1.4 | 1B:2 to 1B:35 | Heating curve slope adjustable from 0.2 to 3.5. Zone circuit 1 |
| 1C:0 | Heating curve level = 0 | 1C:-13 to 1C:40 | Heating curve level adjustable from -13 to 40. Zone circuit 1 |
| 68:14 | Heating curve slope = 1.4 | 68:2 to 68:35 | Heating curve slope adjustable from 0.2 to 3.5. Zone circuit 2 |
| 69:0 | Heating curve level = 0 | 69:-13 to 69:40 | Heating curve level adjustable from -13 to 40. Zone circuit 2 |
| 6A:14 | Heating curve slope = 1.4 | 6A:2 to 6A:35 | Heating curve slope adjustable from 0.2 to 3.5. Zone circuit 3 |
| 6B:0 | Heating curve level = 0 | 6B:-13 to 6B:40 | Heating curve level adjustable from -13 to 40. Zone circuit 3 |


Calling up the Service Level

Press OK and  simultaneously for approximately 4 sec.

Service menu overview




Scanning and resetting the “Service” display

After the limits specified in coding addresses “21” and “23” have been reached, the red fault indicator flashes and “Service” and “” appear on the programming unit display.

Acknowledging and resetting service

Press OK to acknowledge a service message.

Note: An acknowledged service message that was not reset reappears the following Monday.
After a service has been carried out (reset service)

- 1. Press OK and  simultaneously for approx. 4 sec.
- 2. “Service functions”
- 3. “Service reset”

Note: The selected service parameters for hours run and time interval restart at 0.

Instructing the system user

The system installer must hand the operating instructions to system users and instruct them in the operation of the system.


Diagnosis

Scanning operating data

- Operating data can be scanned in six areas.
See "Diagnosis" in the service menu overview.
- Operating data on heating circuits with mixing valves and solar can only be scanned if the components are installed in the system. For further information on operating data, see chapter "Brief scan".

Note: "- - -" appears on the display if a sensor that has been scanned is faulty.

Calling up operating data


1. Press OK and  simultaneously for approximately 4 sec.
2. "Diagnosis"
3. Select required group, e.g. "General"



Refer to Operating instructions

Brief scan

In the brief scan, you can call up temperatures, software versions and connected components, for example:


1. Press OK and  simultaneously for approximately 4 sec.
2. "Diagnosis"
3. "Brief scan".
4. Press OK. The display shows 9 lines with 6 fields each.

| Diagnosis Brief scan | | | | | |
|-------------------------------------------------------------------------------------------------|---|---|---|---|-----|
| 1: | 1 | F | 0 | A | 1 2 |
| 2: | 0 | 0 | 0 | 0 | 0 0 |
| 3: | 0 | 0 | 0 | 0 | 0 0 |
| 4: | 0 | 0 | 0 | 0 | 0 0 |
| Select with  | | | | | |








For an explanation of the relevant values in the individual lines and fields, see the following table:

| Line (brief scan) | Field | | | | | |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------|
| | 1 | 2 | 3 | 4 | 5 | 6 |
| 1: | Software version Control unit | | Equipment version | | Burner control unit version | |
| 2: | System type 01 to 10 | | Number of KM BUS participants | Maximum demand temperature | | |
| 3: | 0 | Software version Programming unit | Software version, Mixing valve extension 0: No mixing valve extension | 0 | Software version, LON module | 0 |
| 4: | Software version Burner control unit | | Type Burner control unit | | Appliance type | |
| 5: | 0 | 0 | | 0 | 0 | 0 |
| 6: | Number of LON participants | | Check digit | Max. output Details in % | | |
| 7: | Heating circuit A1 (without mixing valve) Remote control 0: without 1: Vitotrol 200A 2: Vitotrol 300A or Vitohome | | Heating circuit M2 (with mixing valve) Remote control 0: without 1: Vitotrol 200A 2: Vitotrol 300A or Vitohome | | Heating circuit M3 (with mixing valve) Remote control 0: without 1: Vitotrol 200A 2: Vitotrol 300A or Vitohome | |
| 8: | Internal circulation pump Variable speed pump 0: without 1: Wilo 2: Grundfos | | Heating circuit pump, heating circuit M2 Variable speed pump 0: without 1: Wilo 2: Grundfos | | Heating circuit pump, heating circuit M3 Variable speed pump 0: without 1: Wilo 2: Grundfos | |
| 9: | Internal details for calibration | | | | Software version Extension AM1 | Software version, Extension EA1 |


Checking Outputs (relay tests)

1. Press OK and  simultaneously for approximately 4 sec.
2. "Actuator test"

The following relay outputs can be controlled subject to system design:

| Display | | Explanation |
|--------------------------------------------------------------------------------------------------|-------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| Base load | Start | Burner operated at minimum output; heating circuit A1 pump is on. |
| Full load | Start | Burner operated at maximum output; heating circuit A1 pump is on. |
| Output, internal | Start | Output  active (DHW Pump) enabled. |
| Htg circ pump HC2 | Start | Heating circuit pump output enabled (extension to heating circuit with mixing valve) |
| Mixing valve HC2 | Open | "Mixing valve open" output enabled (extension to heating circuit with mixing valve) |
| Mixing valve HC2 | Close | "Mixing valve closed" output enabled (extension to heating circuit with mixing valve) |
| Htg circ pump HC3 | Start | Heating circuit pump output enabled (extension to heating circuit with mixing valve) |
| Mixing valve HC3 | Open | "Mixing valve open" output enabled (extension to heating circuit with mixing valve) |
| Mixing valve HC3 | Close | "Mixing valve closed" output enabled (extension to heating circuit with mixing valve) |
| Outp. int. exten. H1 | Start | Output at internal extension H1 enabled |
| EA1 output 1 | Start | Contact P - S on plug  for extension EA1 closed |
| Solar circuit pump | Start | Solar circuit pump  output at solar control module SM1 enabled |
| Solar circ pmp min | Start | Solar circuit pump output at solar control module SM1 switched to min. speed |
| Solar circ pmp max | Start | Solar circuit pump output at solar control module SM1 switched to max. speed |
| Solar output  | Start | Output  at solar control module SM1 enabled |
| SA 104 output 1 | Start | DHW recirculation pump output  |
| SA 104 output 2 | Start | Output heating circuit pump A1  |
| SA 104 output 3 | Start | |

Fault Codes



In the event of a fault, red fault indicator (A) flashes. "A" flashes on the display and "Fault" is shown.

The fault code is displayed with OK. For an explanation of the fault code, see the following pages.

For some faults, the type of fault is also displayed in plain text.

Acknowledging a fault

Follow the instructions on the display.

Note: The fault message is transferred to the standard menu. A fault output device (e.g. light, buzzer etc.), if connected, will be switched OFF. If an acknowledged fault is not remedied, the fault message will be re-displayed the following day and the fault output device restarted.

Calling up acknowledged faults


Select "Fault" in the standard menu.

The current faults will be displayed in a list.

Calling up fault codes from the fault memory (fault history)

The 10 most recent faults (including resolved ones) are saved and can be called up.

Faults are sorted by date.

1. Press OK and  simultaneously for approximately 4 seconds
2. "Fault history"
3. "Display?"

Fault Codes *(continued)*

| Fault code on display | System behavior *1 | Cause | Corrective action |
|-----------------------|------------------------------------------------------------|----------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|
| 10 | Boiler operates based on outdoor temperature of 32°F (0°C) | Short circuit on outdoor temperature sensor | Check the outdoor temperature sensor (see page 93). |
| 18 | Boiler operates based on outdoor temperature of 32°F (0°C) | Outdoor temperature sensor cable broken | Check the outdoor temperature sensor (see page 93). |
| 30 | Burner blocked | Short circuit on boiler water temperature sensor | Check the boiler water temperature sensor (see page 94). |
| 38 | Burner blocked | Boiler water temperature sensor cable broken | Check the boiler water temperature sensor (see page 94). |
| 40 | Mixing valve closes | Heating circuit 2 with mixing valve supply short circuit on temperature sensor | Check the supply temperature sensor (see page 94). |
| 44 | Mixing valve closes | Short circuit, supply temperature sensor, heating circuit 3 (with mixing valve) | Check supply temperature sensor (see page 94). |
| 48 | Mixing valve closes | Heating circuit 2 with mixing valve supply temperature sensor cable broken | Check the supply temperature sensor (see page 94). |
| 4C | Mixing valve closes | Supply temperature sensor cable broken circuit 3 (with mixing valve) | Check supply temperature sensor (see page 94). |
| 50 | No DHW heating | Short circuit on DHW tank temperature sensor | Check the DHW sensor (see page 94). |
| 58 | No DHW heating | Tank temperature sensor cable broken | Check the sensor (see page 94). |
| 90 | Control mode | Short circuit, temperature sensor 7 | Check sensor 7 on solar control module |
| 91 | Control mode | Short circuit, temperature sensor 10 | Check sensor 10 on solar control module |
| 92 | No solar DHW heating | Short circuit, collector temperature sensor | Check temperature sensor 6 on solar control module or Vitosolic sensor |
| 93 | Control mode | Short circuit, tank temperature sensor | Check temperature sensor at connection S3 to Vitosolic 100 |
| 94 | No solar DHW heating | Short circuit, tank temperature sensor | Check temperature sensor 5 on solar control module or Vitosolic sensor |
| 98 | Control mode | Lead break, temperature sensor 7 | Check sensor 7 on solar control module |
| 99 | Control mode | Lead break, temperature sensor 10 | Check sensor 10 on solar control module |

*1 Control mode:.....Boiler/burner fully operational (fault code must be verified and reset).
 Burner in fault mode:.....Boiler control requires manual reset before burner can resume operation.
 Burner blocked:If fault cause is corrected, burner resumes operation.

Fault Codes *(continued)*

| Fault code on display | System behavior * 1 | Cause | Corrective action |
|-----------------------|---------------------------------------------------------------|-----------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
| 9A | No solar DHW heating | Collector temperature sensor [6] cable broken | Check the sensor [6] at the solar control module. |
| 9B DO NOT USE | Control mode | Tank temperature sensor cable broken | Check temperature sensor at connection S3 to the Vitosolic solar control. |
| 9C | No solar DHW heating | Tank temperature sensor [5] cable broken | Check temperature sensor [5] on solar control module. |
| 9E | Control mode | No supply rate in collector circuit or flow rate too low or temperature limiter has responded | Check solar circuit pump and solar circuit. Acknowledge fault message. |
| 9F | Control mode | Solar control module faulty | Replace solar control module. |
| A7 | Control mode (stays in factory default setting) | Faulty programming unit | Replace the programming unit. |
| B0 | Burner blocked | Flue gas temperature sensor shorted out | Check flue gas temperature sensor (see page 95). |
| B1 | Control mode (stays in factory default setting) | Communication fault; programming unit (internal) | Check connections and replace programming unit if required. |
| B5 | Control mode (factory default setting) | Internal fault | Replace the control unit. |
| B7 | Burner blocked | Boiler coding card missing, faulty or incorrect boiler coding card | Plug in boiler coding card or replace if faulty. |
| B8 | Burner blocked | Flue gas temperature sensor cable broken | Check flue gas temperature sensor (see page 95). |
| BA | Mixing valve regulates to a supply temperature of 68°F (20°C) | Communication fault - accessory kit for heating circuit 2 with mixing valve | Check extension kit connections and code. |
| BB | Mixing valve regulates to a supply temperature of 68°F (20°C) | Communication error, extension kit for heating circuit 3 (with mixing valve) | Check extension kit connections and code. |
| BC | Control mode without remote control | Communication error, remote control Vitotrol heating circuit 1 (without mixing valve) | Check connections, cable, coding address "A0" in "Heating circuit" group and remote control unit setting. |

*1 Control mode:.....Boiler/burner fully operational (fault code must be verified and reset).
 Burner in fault mode:.....Boiler control requires manual reset before burner can resume operation.
 Burner blocked:If fault cause is corrected, burner resumes operation.

Fault Codes *(continued)*

| Fault code on display | System behavior * 1 | Cause | Corrective action |
|-----------------------|-------------------------------------|--------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| BD | Control mode without remote control | Communication error, remote control Vitotrol heating circuit 2 (with mixing valve) | Check connections, cable, coding address "A0" in "Heating circuit" group and remote control unit setting. For wireless remote control units: Check radio path connections, place remote control unit and wireless repeater close to the boiler. Check KM BUS connection to wireless base station. Replace wireless components. |
| BE | Control mode without remote control | Communication error, remote control Vitotrol heating circuit 3 (with mixing valve) | Check connections, cable, coding address "A0" in "Heating circuit" group and remote control unit setting. For wireless remote control units: Check radio path connections, place remote control unit and wireless repeater close to the boiler. Check KM BUS connection to wireless base station. Replace wireless components. |
| BF | Control mode | Incorrect LON communication module | Replace LON communication module. |
| C1 | Control mode | Communication fault extension EA1 | Check connections. Without extension EA1, set code "35:0" |
| C2 | Control mode | Communication fault - solar control unit or Vitosolic | Check solar control or Vitosolic. |
| C4 | Control mode | Communication fault, Open Therm extension | Check Open Therm extension. |
| C7 | Control mode, max. pump speed | Communication fault-variable speed circulation pump, heating circuit without mixing valve, heating circuit pump A1 | Check setting of coding address "E5". |
| C8 | Control mode, max. pump speed | Communication error, external variable speed heating circuit pump, heating circuit 3 (with mixing valve) | Check setting of coding address "E5" |
| CD NOT USED | Control mode | Communication fault, Vitocom 100 (KM-BUS) | Check connections Vitocom 100 coding address "95" |
| CF | Control mode | Communication fault - LON communication module | Replace LON communication module. |
| D6 | Control mode | Input DE1 reports a fault at extension EA1 | Remove fault at appliance concerned. |
| D7 | Control mode | Input DE2 reports a fault at extension EA1 | Remove fault at appliance concerned. |

*1 Control mode:.....Boiler/burner fully operational (fault code must be verified and reset).
 Burner in fault mode:.....Boiler control requires manual reset before burner can resume operation.
 Burner blocked:If fault cause is corrected, burner resumes operation.

Fault Codes *(continued)*

| Fault code on display | System behavior *1 | Cause | Corrective action |
|-----------------------|-------------------------------------|----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| D8 | Control mode | Input DE3 reports a fault at extension EA1 | Remove fault at appliance concerned. |
| DA | Control mode without room influence | Short circuit on room temperature sensor, heating circuit 1 without mixing valve | Check the room temperature sensor, heating circuit 1 without mixing valve. |
| DB | Control mode without room influence | Room temperature sensor, shorted out heating circuit 2 with mixing valve | Check the room temperature sensor, heating circuit 2. |
| DC | Control mode without room influence | Short circuit, room temperature sensor, heating circuit 3 (with mixing valve) | Check room temperature sensor, heating circuit 3 |
| DD | Control mode without room influence | Room temperature sensor cable broken, heating circuit 1 without mixing valve | Check the room temperature sensor, heating circuit 1 and the remote control setting (see page 94). |
| DE | Control mode without room influence | Room temperature sensor cable broken, heating circuit 2 with mixing valve | Check the room temperature sensor, heating circuit 2 and the remote control settings (see page 94). |
| DF | Control mode without room influence | Room temperature sensor cable broken, heating circuit 3 (with mixing valve) | Check room temperature sensor for heating circuit 3 and remote control settings (see page 94). |
| E0 | Control mode | Fault external LON participant | Check connections and LON participants. |
| E1 | Burner in a fault mode | Ionization current too high during calibration | Check gap between ionization electrode and burner gauze assembly (see page 23). In open flue mode, prevent very dusty conditions for the combustion air. Press reset button R . |
| E3 | Burner in a fault mode | Heat transfer too low during calibration. Temperature limiter caused shutdown. | Ensure adequate heat transfer. Press reset button R . |

*1 Control mode:.....Boiler/burner fully operational (fault code must be verified and reset).
 Burner in fault mode:.....Boiler control requires manual reset before burner can resume operation.
 Burner blocked:If fault cause is corrected, burner resumes operation.

Fault Codes *(continued)*

| Fault code on display | System behavior *1 | Cause | Corrective action |
|-----------------------|------------------------|------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| E4 | Burner blocked | Fault, supply voltage 24V | Replace the control unit. |
| E5 | Burner blocked | Fault flame amplifier | Replace control unit. |
| E7 | Burner in a fault mode | Ionization current too low during calibration | Check ionization electrode: - Distance to burner gauze assembly (see page 23). - Contamination of electrode. - Connecting lead and plug-in connections. Check flue system; remedy flue gas recirculation if required. Press reset button R . |
| E8 | Burner in a fault mode | The ionization current lies outside the permissible range | Check gas supply (gas pressure and gas flow limiter), gas train and connecting lead. Check allocation of gas type (see page 17). Check ionization electrode: - Distance to burner gauze assembly (see page 23). - Contamination of electrode Press reset button R . |
| EA | Burner in a fault mode | The ionization current lies outside the permissible range during calibration (deviation from previous level too great) | Check flue system; remedy flue gas recirculation if required In open flue mode, prevent very dusty conditions for the combustion air. Press reset button R . Following several unsuccessful reset attempts, replace boiler coding card and press reset button R . |
| EB | Burner in a fault mode | Repeated flame loss during calibration | Check gap between ionization electrode and burner gauze assembly (see page 23). Check allocation of gas type (see page 17). Check flue system; remedy flue gas recirculation if required. Press reset button R . |
| EC | Burner in a fault mode | Parameter fault during calibration | Press reset button R or Replace boiler coding card and press reset button R . |
| ED | Burner in a fault mode | Internal fault | Replace control unit. |

***1** Control mode:.....Boiler/burner fully operational (fault code must be verified and reset).
 Burner in fault mode:.....Boiler control requires manual reset before burner can resume operation.
 Burner blocked:If fault cause is corrected, burner resumes operation.

Fault Codes *(continued)*

| Fault code on display | System behavior *1 | Cause | Corrective action |
|-----------------------|------------------------|-----------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| EE | Burner in a fault mode | At burner start, flame signal is missing or too weak | Check gas supply (gas pressure and gas regulator). Check gas train. Check ionization electrode and connecting cable. Check ignition: - Connecting leads to ignition module and ignition electrode. - Ignition electrode gap and contamination (see page 23). Check condensate drain. Press reset button R . |
| EF | Burner in a fault mode | Flame is lost immediately after it has built (during the safety time) | Check gas supply (gas pressure and gas regulator). Check flue gas/ventilation air system for flue gas recirculation. Check ionization electrode (replace if required): - Distance to burner gauze assembly (see page 23). - Contamination of electrode Press reset button R . - Check combustion air/common combustion air intake for blockages. - replace air intake adaptor. |
| F0 | Burner blocked | Internal fault | Replace the control unit. |
| F1 | Burner in a fault mode | Maximum flue gas temperature exceeded 230°F (110°C) limit. | Check heating system fill level. Bleed air from system. Check circulation pump. Check boiler water temperature sensor and cable. Press reset button R after vent system has cooled down. |
| F2 | Burner in fault mode | Fixed high limit switch open (activated) | Check heating system fill level. Check the circulation pump. Bleed air from the system. Check fixed high limit switch and connecting cables. Press reset button R . |
| F3 | Burner in fault mode | Flame signal already present at burner start | Check the ionization electrode and connecting cable. Press reset button R . |


*1 Control mode:.....Boiler/burner fully operational (fault code must be verified and reset).
 Burner in fault mode:.....Boiler control requires manual reset before burner can resume operation.
 Burner blocked:If fault cause is corrected, burner resumes operation.

Fault Codes *(continued)*

| Fault code on display | System behavior *1 | Cause | Corrective action |
|-----------------------|--------------------------------------------------------------|-----------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| F8 | Burner in fault mode | Gas valve closes too late | Check the gas valve. Check both control wiring/connections. Press reset button R . |
| F9 | Burner in fault mode | Fan speed too low during burner start | Check the fan, the fan cables and power supply. Check the fan control. Press reset button R . |
| FA | Burner in fault mode | Fan not at standstill | Check the fan, the fan connecting cables and fan control. Check the fan control. Press reset button R . |
| FC | Burner in fault mode | Gas valve faulty or faulty modulation valve control; or vent system blocked | Check the gas valve. Check the vent system. Press reset button R . |
| FD | Burner in a fault state and additional fault B7 is displayed | Boiler coding card is missing | Insert the boiler coding card. Press reset button R . Replace control unit if fault persists. |
| | Burner in a fault state | Fault, burner control unit | Check ignition electrodes and connecting cables. Check whether a strong interference (EMC) field exists near the appliance. Press reset button R . Replace control unit if fault persists. |
| FE | Burner in fault mode | Damaged or incorrect boiler coding card or main PCB | Press reset button R . If the fault persists, check the boiler coding card or replace it or the control unit. |
| FF | Burner in fault mode | Internal fault or reset button R blocked | Restart the equipment. Replace the control unit if the equipment will not restart. |


***1** Control mode:.....Boiler/burner fully operational (fault code must be verified and reset).
 Burner in fault mode:.....Boiler control requires manual reset before burner can resume operation.
 Burner blocked:If fault cause is corrected, burner resumes operation.

Corrective Action




Accessing the Control Electrical Connections Box

1. Remove the screws from the top panel and set aside.
2. Slide the top panel to the rear of the boiler and lift up.
3. Remove the retaining nuts from the control connection cover and set aside.
4. Slide the control connection cover to the rear of the boiler and lift up.






Checking the outdoor temperature sensor

1. Pull plug "X3" from the control unit.
2. Test the resistance of the outdoor temperature sensor across terminals "X3.1" and "X3.2" on the disconnected plug and compare it with the curve.
3. Where actual values deviate severely from the curve values, disconnect the wires at the sensor and repeat test on the sensor itself.
4. Depending on the result, replace the lead or the outdoor temperature sensor. Sensor type: NTC 10 kΩ



Corrective Action *(continued)*






Checking the DHW / low loss header / heating circuit / room temperature sensor

1. Pull the leads from temperature sensor.
2. Check the sensor resistance and compare it with the curve.
3. Replace the sensor in the case of severe deviation.

Checking the boiler temperature sensor


1. Pull plug **3** and measure the resistance.
2. Check the sensor resistance and compare it with the curve.
3. Replace the sensor in the case of severe deviation.
4. Release the strain relief on the sensor well and pull the sensor out of the well and disconnect plug. Install the new sensor in reverse order.



Corrective Action *(continued)***Checking the flue gas temperature sensor**


The flue gas temperature sensor locks out the boiler when the permissible flue gas temperature is exceeded. Reset the interlock after the flue system has cooled down by pressing reset button R.

1. Pull the leads from flue gas temperature sensor (A).
2. Check the sensor resistance and compare it with the curve.
3. Replace the sensor in the case of severe deviation.

**Checking the boiler fuse**

1. Switch off the power.
2. Remove top panel and cover (see page 93).
3. Check fuse F1 (see connection and wiring diagram).

Corrective Action *(continued)*



Legend

- Ⓐ Integrate EA1 module
- Ⓑ Power/pump connection interface
- Ⓒ Fuse F1 (Integrate EA1 module)
- Ⓓ Fuse F2 (Power/pump connection interface)
- Ⓔ Fuse F1 (Power/pump connection interface)



Checking the electrical connect module fuse

1. Switch off the power.
2. Remove front panel and cover (see page 93).
3. Check fuse F1 and F2 of the power/pump connection interface.
4. Check fuse F1 and F2 of the integrate EA1 module.

Corrective Action *(continued)*

Extension kit for heating circuit with mixing valve
Checking the setting of rotary selector S1

The rotary selector on the PCB of the extension kit defines the assignment to the relevant heating circuit.

| Heating circuit | Rotary selector S1 setting | |
|----------------------------------------------------------|----------------------------|-------------------------------------------------------------------------------------|
| Heating circuit with mixing valve M2 (heating circuit 2) | 2 |  |
| Heating circuit with mixing valve M3 (heating circuit 3) | 4 |  |

Note: The rotational direction of the mixing valve motor during its self-test. Then set the mixing valve manually to “Open”.


Note: The supply temperature sensor must now capture a higher temperature. If the temperature drops, either the motor is turning in the wrong direction or the mixing valve set is incorrectly fitted.


Checking the rotational direction of the mixing valve motor


After being switched on, the boiler implements a self-test. During this, the mixing valve is opened and closed again.

Changing the rotational direction of the mixing valve motor (if required)

1. Remove the upper casing cover of the extension kit.



**WARNING**




Electric shock hazard indicates an imminently hazardous situation which, if not avoided, may result in loss of life, serious injury or substantial product / property damage. Before opening the boiler, disconnect main power.

2. At plug 52, swap the cores at terminals “▲” and “▼”.
3. Refit the casing cover.

Checking the Vitotronic 200-H (accessories)

The Vitotronic 200-H is connected to the control unit via the LON cable. To test the connection, carry out a participant check at the boiler control unit (see page 54).

Internal Extensions EA1



Legend

- DE1 Digital input 1
- DE2 Digital input 2
- DE3 Digital input 3
- 0 – 10V 0 - 10V input
- 40 Power supply
- 40A A Power supply for additional accessories
- 157 Central fault message/ feed pump/DHW recirculation pump (potential-free)
- 145 KM BUS

Refer to main wiring diagram on page 101.

Internal Extensions EA1 *(continued)*

Digital data inputs DE1 to DE3

The following functions can be connected alternatively:

- External heating program changeover for each heating circuit
- External blocking
- External blocking with fault message input
- External demand with minimum boiler water temperature
- Fault message input
- Brief operation of the DHW recirculation pump

External contacts must be dry.

Input function assignment

Select the input functions by means of codes in the "General" group at the boiler control unit:

- DE1: Coding address 3A
- DE2: Coding address 3B
- DE3: Coding address 3C

Assigning the heating program changeover function to the heating circuits

Select the heating program changeover function for the respective heating circuit via coding address D8 in the "Heating circuit" group at the boiler control unit:

- Changeover via input DE1: Code D8:1
- Changeover via input DE2: Code D8:2
- Changeover via input DE3: Code D8:3

The effect of the heating program changeover is selected via coding address D5 in the "Heating circuit" group. The duration of the changeover is set via coding address F2 in the "Heating circuit" group.

Effect of the external blocking function on the pumps

The effect on the respective heating circuit pump is selected in coding address D6 in the "Heating circuit" group.

The effect on a circulation pump for DHW tank heating is selected in coding address 5E in the "DHW" group.

Effect of the external demand function on the pumps

The effect on the respective heating circuit pump is selected in coding address D7 in the "Heating circuit" group.

The effect on a circulation pump for DHW tank heating is selected in coding address 5F in the "DHW" group.

DHW recirculation pump runtime for brief operation

The runtime is adjusted via coding address "3D" in the "General" group.

Analog input 0 - 10V

The 0 - 10V hook-up provides an additional set boiler water temperature:

0 - 1V taken as "no default for set boiler water temperature"

1V $\bar{\lambda}$ set value 50°F (10°C)

10V $\bar{\lambda}$ set value 212°F (100°C)

Ensure DC separation between the ground conductor and the negative pole of the on-site voltage source.

Output 157

The following functions can be connected to output 157:

- DHW recirculation pump
- or
- Fault output device (e.g. light, buzzer etc.)
- or
- Zone circuit pump

Function assignment

Select the function of output 157 via coding address "36" in the "General" group at the boiler control unit.

Control Functions

External heating program changeover

The "External heating program changeover" function is connected via extension EA1. There are 3 inputs available at extension EA1 (DE1 to DE3).

The function is selected via the following codes:

| Heating program changeover | Coding |
|----------------------------|--------|
| Input DE1 | 3A:1 |
| Input DE2 | 3B:1 |
| Input DE3 | 3C:1 |

Assign the heating program changeover function for the respective heating circuit with code D8 at the boiler control unit:

| Heating program changeover | Coding |
|----------------------------|--------|
| Changeover via input DE1 | D8:1 |
| Changeover via input DE2 | D8:2 |
| Changeover via input DE3 | D8:3 |

You can select which direction the heating program changeover takes in coding address "D5":

| Heating program changeover | Coding |
|-------------------------------------------------------------------------------------------------------|--------|
| Changeover towards "Permanently reduced" or "Permanent standby" mode (based on the selected setpoint) | D5:0 |
| Changeover towards "Constant heating mode" | D5:1 |

The duration of the heating program changeover can be adjusted in coding address "F2":

| Heating program changeover | Coding |
|----------------------------------------------------------|---------------|
| No changeover | F2:0 |
| Duration of the heating program changeover 1 to 12 hours | F2:1 to F2:12 |

The heating program changeover stays enabled for as long as the contact remains closed, but at least as long as the duration selected in coding address "F2".

External blocking

The "External blocking" and "External blocking and fault message input" functions are connected via extension EA1. There are 3 inputs available at extension EA1 (DE1 to DE3).

The function is selected via the following codes:

| External blocking | Coding |
|-------------------|--------|
| Input DE1 | 3A:3 |
| Input DE2 | 3B:3 |
| Input DE3 | 3C:3 |

| External blocking and fault message input | Coding |
|-------------------------------------------|--------|
| Input DE1 | 3A:4 |
| Input DE2 | 3B:4 |
| Input DE3 | 3C:4 |

The effect on the internal circulation pump is selected with code 5E. Select the effect on the respective heating circuit pump with code D6.

External demand

The "External demand" function is connected via extension EA1. There are 3 inputs available at extension EA1 (DE1 to DE3). The function is selected via the following codes:

| External demand | Coding |
|-----------------|--------|
| Input DE1 | 3A:2 |
| Input DE2 | 3B:2 |
| Input DE3 | 3C:2 |


The effect on the internal circulation pump is selected with code 5F. The effect on the respective heating circuit pump is selected with code D7.

The minimum set boiler water temperature in case of external demand is selected in coding address "9B".

Zone circuit thermostat inputs

| Zone circuit | Code |
|--------------|------------------------------------------|
| Input DE1 | 3A:7 Constant 3A:8 Weather compensate |
| Input DE2 | 3B:7 Constant 3B:8 Weather compensate |
| Input DE3 | 3C:7 Constant 3C:8 Weather compensate |

Wiring Diagram



! WARNING


**DISCONNECT POWER BEFORE
SERVICING BOILER.**

If any of the original wires as supplied with the appliance must be replaced, it must be replaced with the exact equivalent.

CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

* Only one function/connection may be assigned to each connection.



Wiring Diagram *(continued)***Legend**

| | |
|-------|----------------------------------------------------------------|
| 1 | Outdoor Temperature Sensor |
| 2 | Supply Temperature Sensor/Low Loss Header |
| 3/1 | Boiler Temperature Sensor #1 |
| 3/2 | Boiler Temperature Sensor #2 |
| 5 | DHW Temperature Sensor |
| 11 | Ionization Electrode |
| 15 | Flue Gas temperature Sensor |
| 20 | Boiler Pump |
| 21 | DHW Pump |
| 28/20 | Programmable Pump Output / zone circuit pump output* |
| 35 | Gas Valve |
| 40 | Power Supply |
| 40A | Accessory Power Output |
| 54 | Ignition Transformer |
| 96 | Powered Accessory Connection |
| 100 | Fan Motor |
| 100A | Fan Motor Control |
| 111 | Not Used |
| 145 | KM BUS |
| 147 | Pump Modulation Output 0-10VDC |
| Multi | Powered Accessory Connection |
| 156A | Switched Output F2 |
| 156B | Switched Output F1 |
| DE1 | Digital Input 1 (Dry Contact) |
| DE2 | Digital Input 2 (Dry Contact) |
| DE3 | Digital Input 3 (Dry Contact) |
| 0-10V | 0-10VDC Input |
| 157 | Fault Alarm/DHW Recirculation Pump / zone circuit pump output* |
| 190 | Gas Modulation Coil |

* See wiring diagram


- Ⓐ Boiler Control
- Ⓑ External Accessory Connection Board
- Ⓒ Power/Pump Connection Interface
- Ⓓ Integrate EA1 Module
- Ⓔ KM-BUS for External Devices
- Ⓕ Electrical Junction Box
- Ⓖ Field Wiring Connections
- A1 Main Board
- A2 Internal Power Supply Unit
- A3 Optolink
- A4 Burner Control Unit
- A5 Programming Unit
- A6 Coding Card
- A7 Connection Adaptor
- A8 LON Communication Module
- S1 ON/OFF Switch
- S2 Reset Button
- X.. Electrical Interface

IMPORTANT

Electrical installations must comply with the latest edition of:

- In the U.S.A., the National Electrical Code (NEC), ANSI/NFPA 70 and any other state, local codes and/or regulations.
- In Canada, the Canadian Electrical Code (CEC), CSA C22.1 Part 1 and any other province, territory, local codes and/or regulations.

Fitting the Front Panel



1. Place the front cover onto the locating pegs.
2. Push the top of the panel in place.
3. Secure in place with the retaining screw.

Burner Program Sequence of Operation

| | Stand by | Stand-still status test (blower) | Pre-purge speed test | Pre-purge | Pre-ignition | Ignition / safety timing / flame stabilization | Burner modulation or calibration | Combination gas valve proof and closure test | Post-purge speed test | Additional Post-purge (if initiated) |
|--------------------------|----------|----------------------------------|---------------------------|-----------|--------------|------------------------------------------------|----------------------------------|----------------------------------------------|---------------------------|--------------------------------------|
| Call for heat | | | | | | | | | | |
| Water-flow switch closed | | | | | | | | | | |
| Ignition | | | | | | | | | | |
| Combination gas valve | | | | | | | | | | |
| Flame signal | | | | | | | | | | |
| Fan speed | | | | | | | | | | |
| Fan control | | | | | | | | | | |
| Modulation set point | | | | | | | | | | |
| Phase | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
| Sequence time | | Normal < 1s Max. < 51s | Normal < 1s Max. < 51s | 0.1s | 0.4s | 4.5s | | Normal < 3s Max. < 15s | Normal < 3s Max. < 15s | 0.15s |



Modulation range



Transition

Phase 0: Stand-by

Complete shutdown until the next call for heat. In this phase both the combination gas valve and the blower are not energized.

Phase 1: Stand-still status test (blower)

A call for heat initiates internal blower sensory communications to confirm that the blower is truly in stand-still position. Blower speed measured must be < 300 rpm within a 51 second period.

Phase 2: Pre-purge speed test

Controller sends and receives signal to / from fan speed controller to verify maximum rpm of the blower.

Phase 3: Pre-purge

Pre-purge cycle starts within the pre-programmed timing. Pre-purge timing is in addition to previous phase (2). The fan speed must be greater than and within the range of rpm requested by the controller.

Phase 4: Pre-ignition

The ignition spark is initiated and controlled.

Phase 5: Ignition / safety timing / flame stabilization

The gas valve opens during the safety timing period (4.5 seconds). If a flame is detected, this phase ends immediately in < 1.5 seconds. If the flame is not established after 3 trials, the burner will lock out and will require a manual reset. Controller required time for flame stabilization.

Phase 6: Burner modulation operation or calibration

At the end of the flame stabilization period (4.5 seconds), a release for modulation occurs and the burner temperature controller will take over from the flame safeguard. Forced shutdown after 24 hours continuous operation. Automatic calibration may be initiated by the controller.

Phase 7: Combination gas valve proof of closure test

If during the normal operation of the burner a controlled (or uncontrolled) shut-down occurs, a complete mechanical and electrical gas valve proof of closure test will be performed by the flame safeguard. After a successful mechanical and electrical proof of closure test, the flame safeguard will expect that the flame is not present. If, however, the flame existed for a period of > 15 seconds, the flame safeguard will go into permanent lock-out.

Phase 8: Post-purge speed test

Both gas valves are closed during this phase. End call for heat. Post-purge occurs during the programmed period.

Phase 9: Additional post-purge

If the fixed high limit trips during normal operation, the blower will purge for 15 minutes to cool the heat exchanger.

Parts Lists

| Model No. | Serial No. |
|---------------------|-----------------|
| CU3A 26, 94 Boiler | 7553000□□□□□□□□ |
| CU3A 35, 125 Boiler | 7553001□□□□□□□□ |
| CU3A 45, 160 Boiler | 7553002□□□□□□□□ |
| CU3A 57, 199 Boiler | 7553003□□□□□□□□ |

Ordering Parts:

Please provide Model and Serial Number

Ⓐ when ordering replacement parts. Order replacement components from your Viessmann distributor.

Overview of Assemblies

- Ⓐ Rating Plate and Serial Number
- Ⓑ Enclosure Assembly
- Ⓒ Control Assembly
- Ⓓ Boiler Assembly
- Ⓔ Burner Assembly
- Ⓕ Other Parts (see your Viessmann distributor)

Other Parts (not illustrated)


0300 Installation Set * 1

0404 Parts List, Vitocrossal boiler

0410 Conversion kit, NG > LP

0411 Conversion kit, LP > NG

* 1 For installation sets please see separate parts lists on page 110.




Parts Lists *(continued)*

| Model No. | Serial No. |
|---------------------|-----------------|
| CU3A 26, 94 Boiler | 7553000□□□□□□□□ |
| CU3A 35, 125 Boiler | 7553001□□□□□□□□ |
| CU3A 45, 160 Boiler | 7553002□□□□□□□□ |
| CU3A 57, 199 Boiler | 7553003□□□□□□□□ |

Parts for Main Enclosure Assembly

0001 Spring clip for insulation (set of 4)
 0002 Cover, edge molding
 0003 Accessory pack, front panel hardware
 0004 Insulation blanket
 0005 Accessory pack, insulation
 0006 Top panel, rear
 0007 Front panel
 0008 Top panel, front

0009 Mid panel, control
 0010 Insulation blanket, rear
 0011 Insulation blanket, front
 0012 Accessory pack, mounting fasteners (set of 4)
 0013 Side panel, left/right
 0014 Mounting bracket
 0015 Rear panel
 0016 Mounting bracket, lower/front
 0017 Mid panel, front




Parts Lists *(continued)*

| Model No. | Serial No. |
|---------------------|-----------------|
| CU3A 26, 94 Boiler | 7553000□□□□□□□□ |
| CU3A 35, 125 Boiler | 7553001□□□□□□□□ |
| CU3A 45, 160 Boiler | 7553002□□□□□□□□ |
| CU3A 57, 199 Boiler | 7553003□□□□□□□□ |

Parts for Control Assembly

- 0001 Boiler control
- 0002 Hinge for control housing (each)
- 0003 Coding plug
- 0004 Fuse, T6.3A/250V (set of 10)
- 0005 Fuse holder
- 0006 Vitotronic 200 KW6B assembly
- 0007 Programming unit, Vitotronic 200 HO1B
- 0008 Control housing, with harness
- 0009 Circuit Board (LON, IU100-B30)
- 0010 Accessory pack, plug #20/28/40/21/96
- 0011 Harness, X8/X9/Ionization
- 0012 Harness, gas valve 35
- 0013 Harness, ignition transformer 54/PE
- 0014 Harness, fan 100
- 0015 Harness, expanded functions
- 0016 Harness, pumps 20/21/96
- 0017 Harness, power 40/40A
- 0018 Harness, KM-BUS 145
- 0019 Harness, X7
- 0020 Sensor #1, outdoor (NTC)
- 0021 Sensor #5, DHW immersion (NTC)
- 0022 Sensor #3, boiler (NTC)
- 0023 Circuit board (expanded functions, SA100-B40)
- 0024 Switch, 2-pole
- 0025 Reset button
- 0026 Side cover (set of 2)
- 0027 Accessory pack, small parts for KW6B
- 0028 Side Cover with harness inlet for KW6B
- 0029 Front and side covers for KW6B
- 0030 Circuit board (manual reset, SA125-A00)
- 0031 Circuit board (Optolink, SA115-A20)
- 0032 Replacement extension module EA1
- 0033 Power/pump control module




Parts Lists *(continued)*

| Model No. | Serial No. |
|---------------------|-----------------|
| CU3A 26, 94 Boiler | 7553000□□□□□□□□ |
| CU3A 35, 125 Boiler | 7553001□□□□□□□□ |
| CU3A 45, 160 Boiler | 7553002□□□□□□□□ |
| CU3A 57, 199 Boiler | 7553003□□□□□□□□ |

Parts for Boiler Assembly

- 0001 Sensor well, G ½ L = 150 with clip
- 0002 Test port cap (set of 2)
- 0003 Leveling bolt (each)
- 0004 Clamp for fresh air hose, D70-90 (set of 2)
- 0005 Gasket for flue gas collector
- 0006 Sensor #15, flue gas
- 0007 Condensate siphon
- 0008 Gasket for flue gas
- 0009 Air Intake adaptor
- 0010 Flue gas collector, with gaskets and sensor
- 0011 Bracket for flue gas collector
- 0012 Fresh air hose, flexible, D80
- 0013 Gasket D65 (set of 2)
- 0014 Vent pipe adaptor, with gasket
- 0015 Fresh air adaptor, with gasket and clamp




Parts Lists *(continued)*

| Model No. | Serial No. |
|---------------------|-----------------|
| CU3A 26, 94 Boiler | 7553000□□□□□□□□ |
| CU3A 35, 125 Boiler | 7553001□□□□□□□□ |
| CU3A 45, 160 Boiler | 7553002□□□□□□□□ |
| CU3A 57, 199 Boiler | 7553003□□□□□□□□ |

Parts for Burner Assembly

- | | |
|--------------------------------------------|--------------------------------------------------------------------------|
| 0001 Burner gasket | 0014 Accessory pack for burner parts |
| 0002 Ground terminal (set of 10) | 0015 Ignition module |
| 0003 Matrix burner mesh with gasket | 0016 Gas valve CES10 with gasket |
| 0004 Ignition Electrode with gasket | 0017 Radial fan NRG118 with gaskets |
| 0005 Gasket for ignition electrode | 0018 Sight glass |
| 0006 Gasket for ionization electrode | 0019 Connection pipe 2, NG/LP with gasket |
| 0007 Gasket for NG/LP (set of 5) | 0020 Combustion chamber door assembly (with burner mesh) |
| 0008 Orifice | 0021 Combustion chamber door refractory (with gaskets and insulation) |
| 0009 Connection pipe 1, NG/LP with gaskets | 0022 Combustion chamber door insulation with gaskets |
| 0010 Adaptor CES10 | 0023 Ionization electrode with gasket |
| 0011 Gasket for radial fan | |
| 0012 Gasket for burner mesh | |
| 0013 Turbulator disc | |



Installation Fittings

| Model No. | Serial No. |
|---------------------|-----------------|
| CU3A 26, 94 Boiler | 7553000□□□□□□□□ |
| CU3A 35, 125 Boiler | 7553001□□□□□□□□ |
| CU3A 45, 160 Boiler | 7553002□□□□□□□□ |
| CU3A 57, 199 Boiler | 7553003□□□□□□□□ |

Ordering Parts:

Please provide Model and Serial Number (A) when ordering replacement parts. Order replacement components from your Viessmann distributor.

Parts (Installation Set 7560 593)


- 0301 Air vent with shut-off base, $\frac{3}{8}$ in.
- 0302 Hex bushing, $\frac{3}{4}$ in. x $\frac{3}{8}$ in.
- 0303 Tee, $\frac{3}{4}$ in.
- 0304 Pressure relief valve, 30 psig
- 0305 Nipple, $\frac{3}{4}$ in. x $1\frac{1}{2}$ in.
- 0306 90° Street elbow, $\frac{3}{4}$ in.
- 0307 Nipple, $\frac{3}{4}$ in. x 4 in.
- 0308 Reduction coupling, $1\frac{1}{4}$ in. x $\frac{3}{4}$ in.
- 0309 Temperature and pressure gage *1
- 0311 Reduction tee, $1\frac{1}{4}$ in. x $1\frac{1}{4}$ in. x $\frac{1}{2}$ in.
- 0312 Gas ball valve, $\frac{3}{4}$ in.
- 0313 Combustion air intake adaptor, CPVC 3 in.
- 0314 Reduction tee, 1 in. x 1 in. x $\frac{3}{4}$ in.
- 0315 Sediment Faucet, $\frac{3}{4}$ in.

Other Parts (not illustrated)

- 0316 Parts List, Installation Fittings

*1 Install anywhere in supply piping near boiler.

(B) Vitocrossal boiler see separate Parts List



Technical Data

| Boiler Model No. CU3A | | 26, 94 | 35, 125 | 45, 160 | 57, 199 |
|---------------------------------------------------------------------|-------------------|------------|------------|-------------|-------------|
| Natural Gas / Liquid Propane Gas CSA input | MBH | 19-94 | 25-125 | 43-160 | 43-199 |
| | (kW) | (5.6-27.5) | (7.3-36.6) | (12.6-47) | (12.6-58) |
| CSA output / DOE heating capacity* 1 | MBH | 17.7-87 | 23.3-116 | 40-149 | 40-185 |
| | (kW) | (5.2-25.5) | (6.8-34) | (11.7-43.7) | (11.7-54.2) |
| Net AHRI Rating | MBH | 76 | 101 | 129 | 161 |
| | (kW) | (22) | (30) | (38) | (47) |
| Heat exchanger surface area | ft. ² | 16.7 | 20.7 | 34.1 | 34.1 |
| | (m ²) | (1.5) | (1.9) | (3.2) | (3.2) |
| Min. gas supply pressure | | | | | |
| Natural gas | "w.c. | 4 | 4 | 4 | 4 |
| Liquid propane gas | "w.c. | 10 | 10 | 10 | 10 |
| Max. gas supply pressure *3 | | | | | |
| Natural gas | "w.c. | 14 | 14 | 14 | 14 |
| Liquid propane gas | "w.c. | 14 | 14 | 14 | 14 |
| A.F.U.E. | % | 95 | 95 | 95 | 95 |
| Weight | lbs | 269 | 275 | 352 | 352 |
| | (kg) | (122) | (125) | (160) | (160) |
| Boiler water content | USG | 13.5 | 13.0 | 18.8 | 18.8 |
| | (L) | (51) | (49) | (71) | (71) |
| Max. operating pressure at 210°F (99°C) | psig | 30 | 30 | 30 | 30 |
| | (bar) | (2) | (2) | (2) | (2) |
| Boiler water temperature | | | | | |
| - Adjustable high limit (AHL) range space heating (steady state) | °F | 68-194 | 68-194 | 68-194 | 68-194 |
| | (°C) | (20-90) | (20-90) | (20-90) | (20-90) |
| DHW production | °F | 194 | 194 | 194 | 194 |
| | (°C) | (90) | (90) | (90) | (90) |
| - Fixed high limit (FHL) | °F | 210 | 210 | 210 | 210 |
| | (°C) | (99) | (99) | (99) | (99) |
| Boiler connections | | | | | |
| Boiler heating supply and return | NPTM | 1¼ in. | 1¼ in. | 1¼ in. | 1¼ in. |
| Pressure relief valve | NPTF | ¾ in. | ¾ in. | ¾ in. | ¾ in. |
| Boiler drain | NPTM | 1 in. | 1 in. | 1 in. | 1 in. |
| | NPTF | ¾ in. | ¾ in. | ¾ in. | ¾ in. |
| Gas valve connection | | | | | |

*1 Output based on 140°F (60°C), 120°F (49°C) system supply/return temperature.

*2 Net AHRI rating based on piping and pick-up allowance of 1.15.

*3 If the gas supply pressure exceeds the maximum gas supply pressure value, a separate gas pressure regulator must be installed upstream of the heating system.

Note: For high altitude installation at 10,000 ft. the input for model Vitocrossal 300 CU3A will have an altitude de-rating of 18%.

Technical Data *(continued)*

| Boiler Model No. CU3A | | 26, 94 | 35, 125 | 45, 160 | 57, 199 |
|-----------------------------------------------------------------------------------------|---------|----------|----------|----------|----------|
| Dimensions | | | | | |
| Overall depth | inches | 27 | 27 | 31½ | 31½ |
| | (mm) | 684 | 684 | 801 | 801 |
| Overall width | inches | 26 | 26 | 26 | 26 |
| | (mm) | 660 | 660 | 660 | 660 |
| Overall height (with control interface open) | inches | 67 | 67 | 67 | 67 |
| | (mm) | 1707 | 1707 | 1707 | 1707 |
| Overall height | inches | 61.5 | 61.5 | 61.5 | 61.5 |
| | (mm) | 1562 | 1562 | 1562 | 1562 |
| Flue gas *4 | | | | | |
| Temperature (at boiler return temperature of 86°F (30°C)) | | | | | |
| - at rated full load | °F (°C) | 113 (45) | 113 (45) | 113 (45) | 113 (45) |
| - at rated partial load | °F (°C) | 90 (32) | 90 (32) | 90 (32) | 90 (32) |
| Temperature (at boiler return temperature of 140°F (60°C)) | °F (°C) | 167 (75) | 167 (75) | 167 (75) | 167 (75) |
| Max. condensate flow rate *5 for NG and LPG TS/TR = 104°F/86°F (40°C/30°C) | | | | | |
| | USG/h | 0.9 | 1.2 | 1.6 | 2.1 |
| | (L/h) | 3.43 | 4.62 | 5.95 | 7.92 |
| Condensate connection | | | | | |
| hose nozzle Ø in. | | | | | |
| | | ¾ | ¾ | ¾ | ¾ |
| Boiler flue gas connection *6 | | | | | |
| Ø in. (mm) | | | | | |
| | | 3 (80) | 3 (80) | 4 (110) | 4 (110) |
| Combustion air supply connection | | | | | |
| outer Ø in. (mm) | | | | | |
| | | 3 (80) | 3 (80) | 3 (80) | 3 (80) |
| Sound Rating (A scale) | | | | | |
| - at maximum input | dB | 48 | 55 | 53 | 58 |
| | dB | 32 | 33 | 33 | 33 |
| Standby losses *7 | BTU/hr | 1128 | 1000 | 1120 | 995 |
| | W/hr | 330 | 292 | 328 | 291 |

*4 Measured flue gas temperature with a combustion air temperature of 68°F (20°C).

*5 Based on maximum input rate.

*6 For side wall vent installations (coaxial system):

Do not exceed max. equivalent length specified in the Installation Instructions of the Vitocrossal 300 CU3A Venting System.

Do not attempt to common-vent Vitocrossal 300 CU3A with any other appliance.

Side wall co-axial vent installation must include Viessmann protective screen!

For details refer to the Installation Instructions for the Vitocrossal 300 CU3A Venting System.

*7 Standby losses measured from the boiler temperature sensor well based on a boiler water temperature of 158°F (70°C) and a room temperature of 68°F (20°C).

For information regarding other Viessmann System Technology componentry, please reference documentation of respective product.

Maintenance Record

| Measurements | | Service date: by: | Service date: by: | Service date: by: | Service date: by: | Service date: by: | Service date: by: | Setpoint value |
|----------------------------------------|--------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|------------------|
| Static pressure | "w.c. | | | | | | | max. 14 "w.c. |
| <hr/> | | | | | | | | |
| Running pressure (supply pressure) | | | | | | | | |
| <input type="checkbox"/> Natural gas | "w.c. | | | | | | | 4-14 "w.c. |
| <input type="checkbox"/> LPG | "w.c. | | | | | | | 10-14 "w.c. |
| <i>Check gas type</i> | | | | | | | | |
| <hr/> | | | | | | | | |
| Carbon dioxide content CO ₂ | | | | | | | | |
| ■ at lower end of rated input range | vol.-% | | | | | | | |
| ■ at upper end of rated input range | vol.-% | | | | | | | |
| <hr/> | | | | | | | | |
| Oxygen content O ₂ | | | | | | | | |
| ■ at lower end of rated input range | vol.-% | | | | | | | |
| ■ at upper end of rated input range | vol.-% | | | | | | | |
| <hr/> | | | | | | | | |
| Carbon monoxide content CO | | | | | | | | |
| ■ at lower end of rated input range | ppm | | | | | | | 50 ppm air-free* |
| ■ at upper end of rated input range | ppm | | | | | | | |
| <hr/> | | | | | | | | |
| Ionization current | µA | | | | | | | |

*Fuel type, altitude, venting and other site parameters may change

Lighting and Operating Instructions

FOR YOUR SAFETY READ BEFORE OPERATING


W A R N I N G: If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

- A. This appliance does not have a pilot. It is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.
- B. **BEFORE OPERATING** smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.
WHAT TO DO IF YOU SMELL GAS
 - Do not try to light any appliance.
 - Do not touch any electric switch; do not use any phone in your building.
 - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
 - If you cannot reach your gas supplier, call the fire department.
- C. Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, don't try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- D. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

OPERATING INSTRUCTIONS

1. **STOP!** Read the safety information above on this label.
2. Set thermostat or other operating control to lowest setting.
3. Turn off all electric power to the appliance.
4. This appliance is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.
5. Close main gas shut-off valve.
6. Wait five (5) minutes to clear out any gas. Then smell for gas, including near the floor. If you smell gas, **STOP!** Follow "B" in the safety information above on this label. If you don't smell gas, go to the next step.
7. Open main gas shut-off valve.
8. Turn on all electric power to the appliance.
9. Set thermostat or other operating control to desired setting.
10. If the appliance will not operate, follow the instructions "To Turn Off Gas To Appliance" and call your service technician or gas supplier.

Manual gas shutoff



TO TURN OFF GAS TO APPLIANCE

1. Set thermostat or other operating control to lowest setting.
2. Turn off all electric power to the appliance if service is to be performed.
3. Close main gas shut-off valve.

